

South Carolina Department of Transportation



Electronic Toll Collection System & Related Services

For the
Cross Island Parkway Toll Facility
Hilton Head, South Carolina
Contract P.O.# 231709

TOLL COLLECTOR USER MANUAL

Rev. 0.0

October 1997


LOCKHEED MARTIN



Lockheed Martin IMS

TOLL COLLECTOR USER MANUAL Rev. 0.0

Prepared by:



Mary Thomas, Documentation Manager

Approved by:



James J. Eden, Assistant Project Manager

THIS MATERIAL CONTAINS PROPRIETARY INFORMATION OF *LOCKHEED MARTIN IMS*. DISCLOSURE TO OTHERS, USE OR COPYING WITHOUT EXPRESS WRITTEN AUTHORIZATION OF *LOCKHEED MARTIN IMS* IS STRICTLY PROHIBITED.

**© *LOCKHEED MARTIN IMS*. UNPUBLISHED WORK. ALL RIGHTS RESERVED.
October 17, 1997.**

Lockheed Martin IMS

6660 Riverside Drive, Suite 300 Metairie, LA 70003
Telephone 504-454-7600 Facsimile 504-454-6542



October 18, 1997

W. L. McIlwain
Deputy Director of Administration
South Carolina Department of Transportation
955 Park Street
P. O. Box 191
Columbia, SC 29202-0191

Re: Contract P.O. # 231709

Dear Mr. W.L. McIlwain,

Subject: Toll Collector User Manual Rev. 0.0

This transmittal contains the draft of the Toll Collector User Manual Rev. 0.0. As software is developed, some procedures may change. This will be reflected in subsequent versions.

If you have any questions, please do not hesitate to contact me.

Sincerely,

A handwritten signature in cursive script, reading "J. J. Eden".

J. J. Eden, Project Manager

CC: Tony Frate

Contents

INTRODUCTION	1
1. ELECTRONIC TOLL COLLECTION SYSTEM OVERVIEW.....	1-1
1.1 DESCRIPTION.....	1-1
1.2 OBJECTIVES	1-1
1.3 CROSS ISLAND PARKWAY PLAZA.....	1-2
1.4 SPANISH WELLS ROAD & MARSHLAND ROAD.....	1-3
1.4.1 Lanes / Configuration Types	1-3
1.5 ETC PERSONNEL OVERVIEW	1-4
1.5.1 Customer Service Representative	1-4
1.5.2 Toll Collector	1-4
1.5.3 Senior Toll Collector.....	1-4
1.5.4 Account Clerk.....	1-4
1.5.5 Application System Administration.....	1-5
1.5.6 Maintenance Personnel.....	1-5
1.5.7 Toll Operations Manager.....	1-5
1.5.8 Office Manager	1-5
1.5.9 Toll Superintendent.....	1-6
1.6 LANE TYPES.....	1-7
1.6.1 Attended AVI / Manual.....	1-7
1.6.2 AVI / Unattended / Automatic	1-7
2. ELECTRONIC TOLL COLLECTION EQUIPMENT OVERVIEW	2-1
2.1 AVI EQUIPMENT.....	2-1
2.1.1 Description.....	2-1
2.1.2 Location in Lane / Plaza.....	2-2
2.1.3 Purpose.....	2-2
2.2 AUTOMATIC COIN MACHINES (ACM)	2-3
2.2.1 Description.....	2-3
2.2.2 Location in Lane / Plaza.....	2-4
2.2.3 Purpose.....	2-4
2.3 ENTRY & EXIT TREADLES.....	2-5
2.3.1 Description.....	2-5
2.3.2 Location in Lane / Plaza.....	2-5
2.3.3 Purpose.....	2-5
2.4 VEHICLE DETECTOR ENTRY & EXIT LOOPS.....	2-6
2.4.1 Description.....	2-6
2.4.2 Location in Lane / Plaza.....	2-6
2.4.3 Purpose.....	2-6
2.5 VEHICLE SEPARATOR DEVICE — SAM UNIT.....	2-8



2.5.1 Description.....	2-8
2.5.2 Location in Lane / Plaza.....	2-9
2.5.3 Purpose.....	2-9
2.6 CANOPY TRAFFIC LIGHT (RED / AMBER / GREEN).....	2-10
2.6.1 Description.....	2-10
2.6.2 Location in Lane / Plaza.....	2-10
2.6.3 Purpose.....	2-10
2.7 ISLAND TRAFFIC SIGNAL W/ VIOLATION LIGHT & AUDIBLE ALARM.....	2-11
2.7.1 Description.....	2-11
2.7.2 Location in Lane / Plaza.....	2-11
2.7.3 Purpose.....	2-11
2.8 PATRON FARE DISPLAY.....	2-12
2.8.1 Description.....	2-12
2.8.2 Location in Lane / Plaza.....	2-12
2.8.3 Purpose.....	2-12
2.9 LANE CONTROLLER CABINET	2-13
2.9.1 Description.....	2-13
2.9.2 Location in Lane / Plaza.....	2-13
2.9.3 Purpose.....	2-14
2.10 TOLLBOOTH	2-15
2.10.1 Description.....	2-15
2.10.2 Location in Lane / Plaza.....	2-15
2.10.3 Purpose.....	2-15
2.11 MAGNETIC SWIPE CARD READER	2-16
2.11.1 Description.....	2-16
2.11.2 Location in Lane / Plaza.....	2-16
2.11.3 Purpose.....	2-16
2.12 TOLL COLLECTOR TOUCHSCREEN.....	2-17
2.12.1 Description.....	2-17
2.12.2 Location in Lane / Plaza.....	2-17
2.12.3 Purpose.....	2-18
2.13 RECEIPT PRINTER.....	2-19
2.13.1 Description.....	2-19
2.13.2 Location in Lane / Plaza.....	2-19
2.13.3 Purpose.....	2-20
2.14 COIN COUNTER	2-21
2.14.1 Description.....	2-21
2.14.2 Location in Lane / Plaza.....	2-21
2.14.3 Purpose.....	2-22
2.15 CLOSED CIRCUIT TELEVISION — “CCTV” CAMERA	2-23
2.15.1 Description.....	2-23
2.15.2 Location in Lane / Plaza.....	2-23
2.15.3 Purpose.....	2-23
2.16 VIOLATION IMAGE CAPTURE CAMERA.....	2-24
2.16.1 Description.....	2-24
2.16.2 Location in Lane / Plaza.....	2-24
2.16.3 Purpose.....	2-24
2.17 PC WORKSTATION	2-25
2.17.1 Description.....	2-25
2.17.2 Location in Lane / Plaza.....	2-25
2.17.3 Purpose.....	2-26



2.18 ALPHA SYSTEM.....	2-27
2.18.1 Description.....	2-27
2.18.2 Location in Lane / Plaza.....	2-28
2.18.3 Purpose.....	2-28
2.19 TOLL LANE HARDWARE CONFIGURATION.....	2-29
2.19.1 Description.....	2-29
2.20 TOLL COLLECTION PROCESS DATA FLOW.....	2-30
2.20.1 Purpose.....	2-30
3. DUTIES, RESPONSIBILITIES & PROCEDURES	3-1
3.1 BEFORE STARTING THE SHIFT.....	3-1
3.1.1 Arriving at Toll Plaza.....	3-1
3.1.2 Personal Items.....	3-1
3.1.3 Bulletin Board.....	3-1
3.1.4 Equipment and Uniforms.....	3-2
3.1.5 Supplies.....	3-2
3.1.6 Lane Assignment.....	3-2
3.2 SEED & REVENUE BAGS.....	3-3
3.2.1 Retrieve.....	3-3
3.2.2 Verify.....	3-3
3.2.3 Be Accountable.....	3-4
3.2.4 Procedure to Use During Breaks.....	3-4
3.3 SAFETY PROCEDURES IN THE TOLL LANES.....	3-5
3.3.1 Safety in Approaching the Toll Lane to Start the Shift.....	3-5
3.4 HOW TO APPROACH CUSTOMERS.....	3-6
3.4.1 Be Prepared to Give Information.....	3-6
3.4.2 Personal Conduct.....	3-6
3.4.3 Emergencies.....	3-6
3.4.4 Do Not Ask or Permit Customers to do the Following.....	3-7
3.5 LOGIN TO TOLL COLLECTOR TOUCHSCREEN.....	3-8
3.5.1 Purpose.....	3-8
3.5.2 Process.....	3-8
3.6 OPEN LANE / STANDBY.....	3-11
3.6.1 Purpose.....	3-11
3.6.2 Continue Standby.....	3-12
3.6.3 Open Lane.....	3-12
3.6.4 Standby.....	3-13
3.7 CLASSIFICATIONS 2 - 7.....	3-14
3.7.1 Purpose.....	3-14
3.7.2 Classify (2 - 7).....	3-15
3.7.3 Options.....	3-17
3.8 CLASSIFICATIONS 8 - 15.....	3-19
3.8.1 Purpose.....	3-19
3.8.2 Process.....	3-20
3.8.3 Options.....	3-21
3.9 INSUFFICIENT FUNDS.....	3-23
3.10 GENERATING RECEIPTS.....	3-25
3.10.1 Purpose.....	3-25
3.10.2 Rules.....	3-25
3.10.3 Process.....	3-26
3.11 PRINTING OUT DIRECTIONS.....	3-27



3.11.1 Purpose.....	3-27
3.11.2 Process for Cross Island Parkway.....	3-28
3.12 RECORDING UNUSUAL OCCURRENCES.....	3-29
3.12.1 Purpose.....	3-29
3.12.2 Process.....	3-30
3.12.3 Emergency Vehicles.....	3-32
3.12.4 Maintenance Vehicles.....	3-33
3.12.5 Police.....	3-34
3.12.6 Pass.....	3-35
3.12.7 U-Turn.....	3-37
3.12.8 Scrip.....	3-39
3.12.9 Written.....	3-41
3.13 CCTV.....	3-43
3.13.1 Purpose.....	3-43
3.13.2 Process.....	3-43
3.14 LOGOFF TOLL COLLECTOR TOUCHSCREEN.....	3-44
3.14.1 Purpose.....	3-44
3.14.2 Process.....	3-45
3.15 DEPOSITS.....	3-47
3.15.1 During a Break.....	3-47
3.15.2 At the End of the Shift.....	3-47
3.15.3 Go to the Count Room at the Collector Deposit Station.....	3-47
3.16 DEPOSITS AT HOST / REVENUE & RECONCILIATION.....	3-48
3.16.1 How to Access from the Collector Deposit Station.....	3-48
3.16.2 Screen Displayed.....	3-48
3.16.3 Process.....	3-49
3.17 TOLL COLLECTOR'S CHECKLIST.....	3-57
3.17.1 Policies & Regulations.....	3-57
3.17.2 For Shift, Schedule & Break Information.....	3-57
3.17.3 Before Going to the Lane.....	3-57
3.17.4 For Basic Information on the Toll Collector's Touchscreen.....	3-58
3.17.5 For Processing Toll Collection.....	3-58
3.17.6 For Special Situations.....	3-58
4. POLICIES & REGULATIONS.....	4-1
4.1 SHIFT INFORMATION.....	4-1
4.1.1 7:00 AM - 3:00 PM Shift.....	4-1
4.1.2 3:00 PM - 11:00 PM Shift.....	4-3
4.1.3 11:00 PM - 7:00 AM Shift.....	4-5
4.2 IMMEDIATELY NOTIFY TOLL SUPERINTENDENT / PLAZA SHIFT SUPERVISOR.....	4-7
4.2.1 To Report Equipment not Working Properly.....	4-7
4.2.2 To Report Accidents.....	4-7
4.2.3 Prior to Leaving the Booth.....	4-7
4.2.4 To Report Emergencies.....	4-7
4.2.5 To Report Counterfeit Bills.....	4-7
4.2.6 To Report Change Left by a Customer.....	4-8
4.3 TOLL COLLECTOR CONDUCT.....	4-9
4.3.1 Conduct with Others.....	4-9
4.3.2 Personal Hygiene.....	4-9
4.3.3 Plaza Equipment.....	4-9
4.3.4 Tardiness and Absenteeism.....	4-9



4.3.5	Personal Phone Calls	4-10
4.3.6	Smoking.....	4-10
4.3.7	Operation of an LMIMS Vehicle.....	4-10
4.4	EMPLOYEE SAFETY	4-11
4.4.1	Customers in the Lane.....	4-11
4.4.2	Toll Collectors	4-12
4.5	PASS PLANS	4-13
4.5.1	Cross Island Parkway Toll Plaza Plans.....	4-13
4.6	TOLLBOOTH OPERATION.....	4-16
4.7	EQUIPMENT NEEDED.....	4-17
4.7.1	Toll Collector Change Fund.....	4-17
4.7.2	Toll Collector Key Identifier Card.....	4-18
4.7.3	Toll Collector Cash Drawer	4-18
4.7.4	Toll Collector Nameplate and Badge.....	4-18
4.7.5	Revenue Bag	4-18
4.7.6	Forms.....	4-19
4.8	OPENING THE TOLL LANE	4-20
4.8.1	Security Inspection.....	4-20
4.8.2	Tollbooth / Lane Inspection	4-20
4.8.3	Safety Inspection.....	4-20
4.8.4	Supply Inspection.....	4-21
4.9	OPERATING A MANUALLY ATTENDED TOLL LANE.....	4-22
4.9.1	Logging On.....	4-22
4.9.2	Position for Collecting Tolls.....	4-22
4.10	CLASSIFYING VEHICLES.....	4-23
4.10.1	Vehicle Classification Chart.....	4-23
4.10.2	Island Traffic Signal	4-23
4.11	MAKING CHANGE	4-24
4.12	CASH ACCUMULATION.....	4-25
4.13	UNACCEPTABLE PAYMENTS.....	4-26
4.14	RECEIPTS TO THE PUBLIC.....	4-27
4.15	DIRECTIONS TO MOTORISTS.....	4-28
4.16	COUNTERFEIT MONEY	4-29
4.16.1	Identification Of Counterfeit Bills.....	4-29
4.16.2	Acceptance Of Counterfeit Money	4-29
4.16.3	Customer Counterfeit Change Claim.....	4-30
4.17	SHORT-CHANGE COMPLAINTS	4-31
4.18	REPORTED OVERPAYMENT	4-32
4.19	OPERATING A MANUALLY ATTENDED TOLL LANE WITH ACM OR AVI CAPABILITY	4-33
4.19.1	Logging On To The Lane	4-33
4.19.2	AVI Customers	4-33
4.20	CLOSING A TOLL LANE	4-34
4.20.1	Closing a Lane for Meal or Break Periods.....	4-34
4.20.2	Closing a Lane at the End of a Shift	4-34
4.20.3	Direct Relief.....	4-35
4.21	AD HOC COLLECTIONS - EQUIPMENT MALFUNCTIONS	4-36
4.21.1	The Toll Collector performs the following steps:.....	4-36
4.22	CLOSING OUT AT THE END OF A SHIFT	4-37
4.23	OUTSIDE EMPLOYMENT	4-38
4.24	STANDARDS OF CONDUCT.....	4-39
4.24.1	All CIP Personnel	4-39



4.24.2 Specific to Toll Collection Personnel.....	4-39
4.25 TRAINING AND APPRAISALS.....	4-40
4.25.1 Training.....	4-40
4.25.2 New Employee Appraisals.....	4-40
4.25.3 Annual Appraisals.....	4-40
4.26 DISCIPLINARY ACTION.....	4-41
4.26.1 IMS Guidelines.....	4-41
4.26.2 Documentation Requirements.....	4-41
4.27 GENERAL OFFICE COMMUNICATIONS.....	4-42
4.27.1 The Toll Superintendent.....	4-42
4.27.2 The CIP Office Manager.....	4-42
4.27.3 The Toll Operations Manager.....	4-42
4.28 SAFETY, SECURITY, AND MAINTENANCE.....	4-43
4.28.1 Toll Collection Personnel.....	4-43
4.28.2 Toll Collection Personnel & Maintenance Technicians.....	4-44
4.28.3 Plaza Shift Supervisor.....	4-44
4.28.4 All CIP Personnel.....	4-44
4.29 SUPPLIES & EQUIPMENT.....	4-46
4.30 ROBBERIES AND THREATS.....	4-47
4.30.1 Documentation.....	4-47
4.30.2 Procedures to follow.....	4-47
4.31 UNIFORMS, CLOTHING AND EQUIPMENT.....	4-48
4.31.1 Standard Uniform.....	4-48
4.31.2 Other Clothing Requirements.....	4-48
4.31.3 Equipment.....	4-48
4.31.4 Equipment Issue Form.....	4-48
4.32 SCHEDULING.....	4-49
4.32.1 Holidays, Vacations, and Sick Leave.....	4-49
4.32.2 Tardiness/Absenteeism.....	4-49
4.32.3 Overtime.....	4-50
4.32.4 Holdover.....	4-50
4.33 CUSTOMER RELATIONS.....	4-51
4.33.1 Purpose.....	4-51
4.33.2 Greeting / Appreciation.....	4-52
4.33.3 Knowledge.....	4-52
4.33.4 Appearance.....	4-53
4.33.5 Accuracy.....	4-53
4.34 MONEY LOSSES BY CIP PERSONNEL.....	4-54
4.34.1 Shortages and / or Overages.....	4-54
4.34.2 Disciplinary Action.....	4-54
4.35 EMERGENCIES.....	4-57
4.36 KEY CONTROL.....	4-58
4.36.1 Key Control Responsibilities.....	4-58
4.36.2 Safe Keys.....	4-58
4.36.3 Key Control Box.....	4-58
4.36.4 Key Inventory.....	4-58
4.37 TELEPHONE USE.....	4-59
4.38 CRITICAL LANE FAILURES.....	4-60
4.38.1 Definition.....	4-60
4.38.2 Notifications.....	4-60
4.38.3 Ramp Lanes.....	4-60



4.38.4 Plaza Lanes.....	4-61
4.39 EMERGENCY EVACUATION PROCEDURES.....	4-62
4.39.1 Emergency Evacuation Assistance Plan.....	4-62
4.39.2 Immediate Evacuation	4-62
4.39.3 Timely Evacuation	4-62
4.40 AD HOC TOLL COLLECTION.....	4-63
4.40.1 Documentation.....	4-63
4.40.2 Manual Traffic Direction.....	4-63
4.40.3 Ad Hoc Toll Collection – Attended Lanes.....	4-63
4.40.4 Ad Hoc Toll Collection – Unattended Lanes	4-65
5. LOGIN / APPLICATION ACCESS / EXIT SESSION	5-1
5.1 LOGIN	5-1
5.1.1 Purpose.....	5-1
5.1.2 Process.....	5-1
5.2 APPLICATION ACCESS.....	5-2
5.2.1 Purpose.....	5-2
5.2.2 To Access the ETC Applications	5-2
5.2.3 Access Host / Revenue Reconciliation Application.....	5-4
5.3 EXIT SESSION.....	5-5
5.3.1 Purpose.....	5-5
5.3.2 Process.....	5-5
6. USING WINDOWS APPLICATIONS.....	6-1
6.1 USING A MOUSE.....	6-1
6.2 MENUS & TOOLBARS.....	6-2
6.2.1 To Use the Main Menu Bar.....	6-2
6.2.2 To Use the Main Toolbar.....	6-2
6.3 TAB FOLDERS.....	6-3
6.3.1 Process.....	6-3
6.4 LIST DROP BOX SELECTIONS	6-4
6.4.1 To Use a List Drop Box.....	6-4
6.5 DATA WINDOWS	6-5
6.5.1 To View All Selections in a Data Window	6-5
6.6 SCROLL BARS.....	6-6
6.6.1 To Use a Scroll bar in a List Drop Box	6-6
6.7 BUTTONS & HOTKEYS	6-8
6.7.1 How to Use Toolbar Buttons.....	6-8
6.7.2 How to Use Command Buttons.....	6-8
6.7.3 How to Use Radio Buttons.....	6-9
6.7.4 How to Use Hotkeys.....	6-9
7. USING ON-LINE HELP.....	7-1
7.1 TOOLBAR BUTTONS	7-1
7.1.1 Contents	7-1
7.1.2 Print.....	7-2
7.1.3 Back.....	7-2
7.1.4 Back Browse Button <<.....	7-3
7.1.5 Forward Browse Button >>	7-3
7.1.6 Search.....	7-3
7.1.7 Glossary.....	7-5



7.1.8 Exit.....	7-5
7.2 SPECIAL FEATURES.....	7-6
7.2.1 If Statements.....	7-6
7.2.2 Jumps or Hotspots.....	7-6
7.2.3 Secondary Windows.....	7-6
7.3 JUMPS OR HOTSPOTS.....	7-7
7.3.1 To Choose A Jump.....	7-7
7.3.2 To Close A Pop-Up Window.....	7-7
7.4 SECONDARY WINDOWS.....	7-8
7.5 DEFINING AND USING BOOKMARKS.....	7-9
7.5.1 Placing a Bookmark in a Topic.....	7-9
7.5.2 Viewing a Bookmark in a Topic.....	7-9
7.5.3 Removing a Bookmark.....	7-9
GLOSSARY OF TERMS.....	1



Introduction

The Toll Collector User Manual has been designed to assist the Toll Collector in the making the transition to the new application software that is being installed at the Cross Island Parkway Operations Building.



The document has been organized in the following manner:

Electronic Toll Collection System Overview

The following general System information is provided:

- Electronic Toll Collection System Overview - Chapter 1
- Electronic Toll Collection Equipment Overview - Chapter 2

Use of Windows Applications

For users that are inexperienced with computers and Windows applications, the following information is available:

- Using Windows Application - Chapter 6
- Using On-Line Help - Chapter 7

Use of the New Software Applications as it relates to the General Duties & Responsibilities of the Toll Collectors

- Login / Application Access / Exit Session - Chapter 5
- General Duties & Responsibilities - Chapter 3
 - ⇒ Users are shown how to use the new software applications in connection with their duties and responsibilities within the facility. This has been accomplished by presenting detailed procedures in a step by step format, beginning with the start of a shift through the end of shift.
- Policies & Regulations - Chapter 4

**1. ELECTRONIC TOLL
COLLECTION SYSTEM
OVERVIEW**

1. Electronic Toll Collection System Overview

1.1 Description

The Cross Island Parkway Toll Facilities are open to traffic and staffed by Toll Collectors twenty-four (24) hours a day, seven (7) days a week. The Cross Island Parkway Toll Collection System is designed to accommodate the rigorous demands of peak traffic hours without delays in toll collection. The system operates without loss of data in any mode of operation.

1.2 Objectives

The objectives of the Cross Island Parkway Toll Collection System are to:

- Collect tolls quickly and efficiently
- Enable rapid traffic flow through the Plaza
- Prevent loss of revenue
- Provide on-line lane audits
- Provide a user-friendly environment for operating personnel

1.3 Cross Island Parkway Plaza

The Cross Island Parkway Plaza Operations Building houses the central equipment for the Cross Island Parkway Electronic Toll Collection System. It has twelve (12) operating toll collection lanes. Three physical lanes are bi-directional as indicated below.

- The ACM collects tolls by means of an automatic coin machine mounted in a stand-alone cabinet.
- The customer displays a properly mounted AVI transponder
- The AVI / Unattended / Automatic lanes may not be operated as attended

1.4 Spanish Wells Road & Marshland Road

Spanish Wells Road and Marshland Road are single lane ramps. Both lanes are AVI / Automatic and unattended.

1.4.1 Lanes / Configuration Types

Lane	Lane Configuration	Type
1	Attended AVI	AVI & MLT
2	Attended AVI	AVI & MLT
3	Attended AVI	AVI & MLT
4N	Attended AVI	AVI & MLT
4S	Attended AVI	AVI & MLT
5N	Attended AVI	AVI & MLT
5S	Attended AVI	AVI & MLT
6N	Attended AVI	AVI & MLT
6S	Attended AVI	AVI & MLT
7	Attended AVI	AVI & MLT
8	Attended AVI	AVI & MLT
9	Attended AVI	AVI & MLT
10	AVI / Automatic	ACM & AVI
11	AVI / Automatic	ACM & AVI

1.5 ETC Personnel Overview

1.5.1 Customer Service Representative

- Works at the Service Center selling the Palmetto Pass
- Updates / closes customer accounts
- Takes replenishments from customers
- Reviews violation images

1.5.2 Toll Collector

- Works in the toll booth, classifies vehicles, takes toll payments, gives receipts and directions to main landmarks
- Responsible for collecting and accounting for all toll payments received

1.5.3 Senior Toll Collector

- Works in the absence of the Plaza Shift Supervisor as required.
- Works in the toll booth, classifies vehicles, takes toll payments, gives receipts and directions to main landmarks
- Responsible for collecting and accounting for all toll payments received

1.5.4 Account Clerk

- Prepares seed / device bags for Toll Collectors and Customer Service Representatives
- Counts and records deposits of toll collections from Toll Collectors and payments from Customer Service Representatives
- Prepares toll revenue for deposit
- Records all incoming and outgoing revenue transactions in the system
- Performs general office duties

1.5.5 Application System Administration

- Establishes system security controls for all personnel
- Updates and monitors system tables
- Monitors communications between Host and PC
- Performs backup, recoveries, and system connections

1.5.6 Maintenance Personnel

- Performs preventative maintenance
- Performs maintenance on the toll collection equipment
- Coordinates and monitors activities of maintenance sub-contractors

1.5.7 Toll Operations Manager

- Responsible to the SCDOT for toll operations
- Insures that toll payments are collected and revenue is accounted for
- Responsible for the complete oversight and operation of the toll plaza

1.5.8 Office Manager

- Performs Human Resources tasks as required
- Performs supervision of Service Center operations
- Reviews AVI revenue reports for inconsistencies
- Maintains inventory of all equipment and supplies

1.5.9 Toll Superintendent

- Oversees the duties of Toll Collectors and Pass Sales Clerks
- Performs non-routine activities and addresses customer inquiries
- Enters maintenance requests and follow up
- Monitors toll lane activity / Service Center activity

1.6 Lane Types

The Cross Island Parkway Electronic Toll Collection System utilizes two types of lanes:

- Attended AVI
- AVI / Unattended / Automatic

1.6.1 Attended AVI / Manual

- Lanes are configured for both manual and AVI toll collection
- Automatic Coin Machines (ACM) can be added to these lanes at a future date


1.6.2 AVI / Unattended / Automatic

- Permit the customer to use either causeway card AVI or ACM payments
- The ACM collects tolls by means of an automatic coin machine mounted to the Toll Collector booth
- The customer swipes a causeway card through a card reader and inputs a personal identification number on a keypad
- The AVI / Unattended / Automatic lanes may be operated as unattended or attended

**2. ELECTRONIC TOLL
COLLECTION EQUIPMENT
OVERVIEW**

2. Electronic Toll Collection Equipment Overview

2.1 AVI Equipment



2.1.1 Description

The AVI subsystem consists of:

- AVI transponders (Palmetto Pass)
- Programming units
- Antenna, Radio Frequency (RF) Modules
- AVI reader devices


2.1.2 Location in Lane / Plaza

- The AVI Transponder is affixed to the patron's vehicle windshield or the front license plate. The patron can obtain a transponder from the Cross Island Parkway Service Center.
- The Programmer unit is located at the Service Center.
- The AVI antenna is located strategically in the lane so that it can capture the signal from the transponders.
- The RF module is located in the roadside AVI reader device cabinet.
- The AVI reader device is located in the roadside AVI reader device cabinet.
- The AVI equipment is located at the Cross Island Parkway plaza, Spanish Wells Road ramp and Marshland Road ramp.

2.1.3 Purpose

- The transponder is the device that the customer affixes to either their windshield or front license plate. The reader confirms a customer's account balance and decreases the account at each use by the amount of the toll.
- The programmer unit is used to enter an ID code into the transponder itself. This is done at the Service Center before issuing a transponder to the customer.
- The AVI antenna is mounted in the lane and is used to transmit and receive transponder class and account data. It interfaces with the RF module to read the signal that is sent from the transponder and sends it to the AVI reader device.
- The RF module interfaces with the AVI antenna and generates a continuous wave-signal off the antenna. When a vehicle bearing a transponder enters a lane and comes into range of the signal, the transponder detects and transmits a signal back to the antenna. The RF module accepts and transfers the return signal and sends it to the AVI reader.
- The AVI reader device reads information from the transponder mounted on the vehicle and transmits it to the Lane Controller for ID verification and sufficient account balance check. Once lane controller account verification is complete, the Lane Controller brings about the appropriate Patron Fare Display, Traffic Control Light (red, amber, or green).

2.2 Automatic Coin Machines (ACM)



2.2.1 Description

- The Automatic Coin Machine (ACM) can be either freestanding or mounted on the side of a tollbooth. Collected coins are stored in an internal vault.
- An ACM is equipped with:
 - ⇒ Patron "Payment Received" Fare Display screen
 - ⇒ Coin Hopper
 - ⇒ Escrow window which can hold up to ten (10) quarters

2.2.2 Location in Lane / Plaza

- The ACM is mounted in a stand-alone cabinet
- Located only at the Spanish Wells Road and Marshland Road ramps

2.2.3 Purpose

- The ACM can detect coin diameter, thickness and metallic content.
- As coins are deposited, the Patron Fare Display decrements the initial toll due by the value of each coin deposited.
- The Patron Fare Display delivers toll messages to the patron.
- Once coins are processed, up to 10 quarters are held in the escrow window, then dropped into the internal vault in the lower section of the ACM cabinet.

2.3 Entry & Exit Treadles



2.3.1 Description

Treadles are devices that are either 8' or 10' long and approximately 12" in width.

They are strategically embedded in the roadway in a toll lane and resemble a black rubber pad.


2.3.2 Location in Lane / Plaza

Treadles are located at the exit of each toll lane.

2.3.3 Purpose

- Treadles classify a vehicle by registering the number of axles.
- Each lane has an exit, two or four-contact treadles.
- The contact treadle detects forward and backward motion of a vehicle's tires as they cross the treadle.
- If a two-axle vehicle crosses the Treadle in a forward motion, two forward axles are registered, and if a two-axle vehicle crosses the Treadle in reverse, two reverse axles are registered.
- This is important for auditing purposes, particularly when there is a violation or unusual occurrence.

2.4 Vehicle Detector Entry & Exit Loops



2.4.1 Description

- A Vehicle Detector Loop is a device that is embedded into the pavement and forms a closed circuit loop.
- The detector loop's electronic properties change when a metallic presence is detected.
- The Vehicle Detector Loop is monitored by the vehicle loop detector and outputs a presence signal when it senses metal.

2.4.2 Location in Lane / Plaza

Vehicle Detector Loops are located:


- At the entrance and exit of multi-mode lanes
- At the exit of all lanes

2.4.3 Purpose

- When a vehicle enters the lane, the entry Vehicle Detection Loop enables various lane devices:
 - ⇒ The AVI equipment
 - ⇒ The Lane Controller advises that there is a vehicle in the lane

- When the vehicle exits over the exit Vehicle Detection Loop, the following changes occur:
 - ⇒ The Island Traffic Light changes to red
 - ⇒ The VES camera takes an image capture of the license plate
 - ⇒ Lane signs return the lane to open status, ready for the next vehicle

2.5 Vehicle Separator Device — SAM Unit



2.5.1 Description

Sensing and Activating Module (SAM) is an infrared laser device. The modulated laser light is transmitted across the toll lane and reflected back from any object that it views. The output is transmitted to the Lane Controller for processing.

SAM is able to detect the following:

- Presence of a vehicle
- Direction of travel
- Velocity
- Height

2.5.2 Location in Lane / Plaza

SAM is located:

- In each multi-mode lane
- At the collection point of the toll lane

2.5.3 Purpose

SAM is similar to the Light Curtain in that it detects the separation between vehicles.

The data output is compared with the pre-classification information in the Lane Controller and ensures that the class of tag the read matches the classification of the vehicle.

2.6 Canopy Traffic Light (Red / Amber / Green)

2.6.1 Description

The Canopy Traffic Lights are visual traffic control devices that consist of a RED, AMBER and GREEN light.

2.6.2 Location in Lane / Plaza

The Canopy Traffic Lights are located:

- Mounted on the plaza canopy above the toll lane
- One both the north and south sides of the canopy in the bi-directional lanes

2.6.3 Purpose

The Canopy Traffic Light alerts approaching drivers as to the lane status — OPEN for manual toll collection and AVI (GREEN), OPEN for AVI only (Flashing AMBER) or CLOSED (RED).

2.7 Island Traffic Signal w/ Violation Light & Audible Alarm

2.7.1 Description

The Island Traffic Signal is a visual three-light, traffic control signal. The Island Traffic Signal consists of a RED light, an AMBER light and a GREEN light with a RED violation indicator mounted on the top of the housing.

2.7.2 Location in Lane / Plaza

The Island Traffic Signal is located:

- At the end of all toll lanes

2.7.3 Purpose

- The Island Traffic Signal controls the flow of traffic in the toll lane.
- The Island Traffic Signal is RED when a vehicle enters the lane.
- As the lane identifies AVI transponders, an AMBER light will appear if there is a Low Balance or other problem with the AVI account.
- The GREEN light is triggered by a successful toll collection.
- The Island Traffic Signal turns RED again once the exit loop registers the vehicle's exit.
- The RED violation beacon and the sound alarm activate when a toll violation is registered.

2.8 Patron Fare Display

2.8.1 Description

The Patron Fare Display (PFD) is a multi-flip, dot matrix display. The device uses magnetic fields and rotating magnetic disks to display messages.

2.8.2 Location in Lane / Plaza


The PFD is located:

- On the left exit side of the toll lane

2.8.3 Purpose

The PFD indicates customer tolls in dollars and cents and exhibits certain messages such as "Thank You". The information displayed is determined by the signals sent from the Lane Controller.

2.9 Lane Controller Cabinet



2.9.1 Description

- The Lane Controller consists of a Pentium 586 IBM compatible PC and various input and output devices.
- The PC is used to process all of the input data and generate outputs to the various lane devices such as the island traffic light, etc.

2.9.2 Location in Lane / Plaza

The Lane Controller is located:

- In the tunnel under the Cross Island Parkway plaza.
- Within a stand-alone cabinet at the Spanish Wells Road and Marshland Road ramps.

2.9.3 Purpose

- The Lane Controller is the foundation of ALL message processing.
- The Lane Controller has customized software that controls the peripheral lane equipment.
- It is the processor that interfaces between the plaza computer and lane equipment.
- The Lane Controller is responsible for monitoring activity in the lane and for providing the appropriate output signals to the lane equipment.

2.10 Tollbooth

2.10.1 Description

The Tollbooth is the structure that houses the following toll collection equipment:

- Touchscreen
- Receipt printer
- Cash drawer
- Security alert system
- All other equipment necessary to operate these lanes manually

The Tollbooth is constructed of stainless steel.

2.10.2 Location in Lane / Plaza


The Tollbooths are located:

- In manual and mixed mode lanes
- On the islands at the collection point
- At the Cross Island Parkway plaza only

2.10.3 Purpose

- The Tollbooth houses the touchscreen and the receipt printer, where the Toll Collector carries out toll collection functions.
- The Tollbooth is where the Toll Collector is stationed during his / her shift.

2.11 Magnetic Swipe Card Reader



2.11.1 Description

- The Magnetic Swipe Card Reader is comprised of a single reader mounted in the proximity of the Manual Lane Terminal.
- The Card Reader interfaces with the lane controller.

2.11.2 Location in Lane / Plaza

The Magnetic Swipe Card Readers are located:


- In the Tollbooths of all Cross Island Parkway plaza lanes

2.11.3 Purpose

The Magnetic Swipe Card Reader is used by the Toll Collectors and other Cross Island Parkway personnel:

- To login into the lane controller
- To contact toll transactions involving any future use of a swipe card.

2.12 Toll Collector Touchscreen



2.12.1 Description

- The Touchscreen is an LCD display that uses an infrared grid to perform the touch location.
- The Touchscreen is housed in a rugged, water-tight housing, suitable for use in the toll environment.
- The Touchscreen interfaces with the lane controller PC.

2.12.2 Location in Lane / Plaza

The Touchscreen is located:

- In every manual toll collection lane
- At the Cross Island Parkway plaza only




2.12.3 Purpose

The Touchscreen features a screen display of buttons. By touching the appropriate button on the Touchscreen, the Toll Collector can:

- Classify vehicles
- Generate patron receipts upon request
- Process unusual occurrences
- Perform a variety of other functions

2.13 Receipt Printer



2.13.1 Description

- The Receipt Printer is a dot matrix printing mechanism that uses parallel communication to transmit to the lane PC.
- The Receipt Printer outputs a paper receipt upon request.

2.13.2 Location in Lane / Plaza

The Receipt Printer is located in:

- All manual lanes
- At the counter beside the Toll Collector Touchscreen

2.13.3 Purpose

- The Receipt Printer is installed in the Tollbooths in the manual / AVI lanes.
- The Toll Collector issues the receipt command to the Receipt Printer from the Toll Collector Touchscreen when a customer requests a receipt.
- When the paper supply is low, a “paper low” message displays on the Toll Collector Touchscreen.
- Only the Plaza Shift Supervisor or maintenance personnel will change the paper in the Receipt Printer.
- The Receipt Printer provides a paper receipt upon request with directions to locations that are commonly asked about.

2.14 Coin Counter



2.14.1 Description

- The Coin Counter is a specialized piece of equipment that counts coins.
- The Coin Counter is equipped to detect the size of all coins and count them.
- The equipment is connected to the system to record the amounts for auditing purposes.

2.14.2 Location in Lane / Plaza

The Coin Counter is located:


- In the Cross Island Parkway Operations building



2.14.3 Purpose

- The Coin Counter is used by the Toll Collectors to count coin revenue collected in the lanes.
- The Coin Counter is used by the Toll Superintendent to count the coins deposited in the ACMs.
- The Coin Counter is used by the Account Clerk to verify the coin deposits of the Toll Collectors.
- Coins are accurately recognized by denomination and counted.
- The totals are recorded by the system.

2.15 Closed Circuit Television — “CCTV” Camera



2.15.1 Description

Closed Circuit Television (CCTV) is a system of cameras that allows the images being captured to be viewed on a television screen.

2.15.2 Location in Lane / Plaza

The CCTV cameras are located:

- In strategic locations around the plaza and remote ramps.
- In the counting, vault and other rooms within the Operations Building.
- In the Cross Island Parkway plaza tunnel.

2.15.3 Purpose

- The CCTV system is used primarily for security purposes.
- CCTV cameras are strategically located to record accesses to the building, toll collection lanes, and counting room activities.

2.16 Violation Image Capture Camera

2.16.1 Description

- The Violation Image Capture Camera is a specialized camera that captures digitized images.
- The system captures and records digitized images when triggered by pre-specified criteria.
- The Violation Image Capture Camera is encapsulated in a heavy duty housing to protect the camera from damage.

2.16.2 Location in Lane / Plaza


Violation Image Capture Cameras are:

- Located in each lane
- Attached to the island, beyond the Tollbooth or ACM cabinet

2.16.3 Purpose

- The Violation Image Capture Camera captures the back of each vehicle as it exits the lane.
- The system records the following vital information that is stored with each capture:
 - ⇒ Date and time of day
 - ⇒ Plaza and lane number

2.17 PC Workstation



2.17.1 Description

The standard PC workstations at the Cross Island Parkway Operations Building and satellite service center locations are:

- Mhz Pentium Processors
- mb RAM
- GB Hard Drive
- CD ROM

A magnetic swipe card reader is located next to each PC workstation. Each user must insert their card into the reader in order to gain access to the software applications.


2.17.2 Location in Lane / Plaza

The PC workstations are located in the Service Center, the Toll Operations Manager's offices, at the Toll Superintendent's office, the Maintenance Shop, and the Toll Collector deposit area.

2.17.3 Purpose

The PC workstations are connected through the network to the Alpha host system. The PC workstations support the application software and communicate with the host to access and supply new data to and from the various databases.

2.18 Alpha System



2.18.1 Description

The Alpha is the host system used by the Cross Island Parkway to support the causeway's computerized system.

- Digital Alphaserver 1000
- MB RAM
- 20GB Tape
- Disks

1	RAID-5	17.1GB
1	STRIPE	8.6GB
1	SHADOW	4.3GB

2.18.2 Location in Lane / Plaza

The Alpha system is located at the Cross Island Parkway Operations Building.

2.18.3 Purpose

The Alpha system is the host system that supports the Cross Island Parkway computerized Electronic Toll Collection System. The host system houses the main 'brains' that receive, process and store all of the information that is sent through the different peripherals to the host. The peripherals are the Electronic Toll Collection Equipment, the Lane Controllers, the Service Center, VES and administrative workstations.

The databases are configured to be able to store and retrieve data upon request. This allows the county to provide a completely audible system that tracks the funds from the point that a customer pays his / her toll to the deposit of that toll into the bank.

2.19 Toll Lane Hardware Configuration

2.19.1 Description

The following diagram is a plan view of a typical toll lane at the Cross Island Parkway plaza. This is designed to show the location of the equipment in the lane.

2.20 Toll Collection Process Data Flow

2.20.1 Purpose

The following flow chart is representative of how and when the equipment is enabled in a toll collection lane when a vehicle passes through

3. Duties, Responsibilities & Procedures

3.1 Before Starting the Shift

3.1.1 Arriving at Toll Plaza

Arrive PRIOR to scheduled shift to prepare for work.

3.1.2 Personal Items

- Bring all items required during shift into the office as the parking lot is off limits during a shift.
 - ⇒ All personal items not required for toll collection, except clear plastic beverage containers must be put in employee lockers.
 - ⇒ Personal money is not allowed in the booths or the lanes.
 - ⇒ Televisions and binoculars are not allowed on the premises of the Cross Island Parkway.

3.1.3 Bulletin Board

- Review the bulletin board for any new or special instructions.
- Obtain prior approval from the Toll Superintendent / Plaza Shift Supervisor for posting or removing items on the board.

3.1.4



Equipment and Uniforms

- Wear required safety vests.
 - ⇒ Wear these items before proceeding into the lanes.
 - ⇒ These items must not be removed while working.
 - ⇒ Employees who forget their vests must use loaners from the office and return them after their shift.
 - ⇒ Employees consistently using loaners may be subject to progressive counseling / discipline.

3.1.5



Supplies

- Bring the following items to the lane:
 - ⇒ Pen
 - ⇒ Envelope
 - ⇒ Money wrappers
 - ⇒ Revenue and seed bags issued by the Toll Superintendent / Plaza Shift Supervisor

3.1.6



Lane Assignment

- Get lane assignment from Toll Superintendent / Plaza Shift Supervisor.

3.2



Seed & Revenue Bags



Remember to view shift and lane assignment information:

- See **Shift Information**, section 4.1.

3.2.1 Retrieve

- After leaving the Collector Deposit Workstation with the lane assignment, retrieve:
 - ⇒ Toll Collector seed bag
 - ⇒ Revenue bags. There are two or more revenue bags issued. The bills, scrip and written unusual occurrences will be put in one revenue bag at the time of deposit and the coins will be put in the other revenue bag at the time of deposit.



If the Toll Superintendent / Plaza Shift Supervisor is not in, the Account Clerk will distribute the bags.

3.2.2 Verify

- In front of the Toll Superintendent / Plaza Shift Supervisor, verify the contents of the seed bag (sealed in a small plastic security bag) with the Account Clerk. This takes place in the Count Room monitored by a video camera.



If any cash or other items are missing from the Toll Collector's seed bag or the relief seed bag, notify the Toll Superintendent / Plaza Shift Supervisor immediately.

3.2.3 Be Accountable



Leaving the office, the Toll Collector is responsible for the full amount of money in the seed bags and toll revenue Bags.



The seed bag shall always be in your possession. Seed bags or toll revenues are NEVER to be left unattended or unsecured.

3.2.4 Procedure to Use During Breaks

1. Prepare seed bag to turn in during first break.
 - It must contain \$200
2. Place cover on cash tray and lock it.
3. Lock tray in tollbooth bottom drawer. Keep the key with you.
4. Make the seed bag deposit at the Collector Deposit Station or the Toll Superintendent / Plaza Shift Supervisor Station, if not being used.



3.3



Safety Procedures in the Toll Lanes

3.3.1 Safety in Approaching the Toll Lane to Start the Shift

1. Check for oncoming traffic.
2. Proceed to assigned lane.
3. Inspect toll booth at start of shift for:
 - A properly functioning toll booth door
 - Proper placement of electric panel cover
 - A safe and stable chair or stool
4. Report any problems to the Toll Superintendent / Plaza Shift Supervisor immediately.
5. Must be in assigned lanes and ready to collect tolls at the start of scheduled shift.

For all other safety procedures see **Employee Safety**, section 4.4.



3.4



How to Approach Customers

3.4.1 Be Prepared to Give Information

- Provide Pass Plan Information - See **Pass Plans**, section 4.5.
- Provide directions for customers - See **Printing Out Directions**, section 3.11.

3.4.2 Personal Conduct

- Use good judgment and be professional.
- Be pleasant, a smile is always helpful!
- Always make a reasonable effort to prevent customers from getting out of their car while the vehicle is stopped in the lane.
- Always be in a position of readiness as a vehicle approaches the assigned toll lane. In the event the driver loses control, the Toll Collector will be in a better position to move back in the booth for safety.
- Never make an attempt to collect a toll from a vehicle that is moving.
- Never attempt to reach inside a moving vehicle or walk alongside a moving vehicle, especially a truck or bus.

3.4.3 Emergencies

- Never open the door of any vehicle except in the case of an emergency.
- If a holdup occurs, NEVER offer any resistance.
- Never detain the driver or any vehicle in an effort to enforce the law unless:
 - ⇒ The driver of the vehicle or the load being hauled is a potential hazard to other parkway customers or can possibly cause damage to the property.
 - ⇒ The law pertinent to the use of vehicular crossings is being violated in regard to vehicle type and size, or the vehicle consists of material which is prohibited or restricted on the parkway.
 - ⇒ A particular vehicle needs to be detained.

3.4.4 Do Not Ask or Permit Customers to do the Following

- Never request a driver of a vehicle to push or tow another vehicle.
- Never request customers to get out of their vehicle to retrieve any object, including toll payment, which may have fallen or dropped into the toll plaza area.
- Never direct drivers to stop their car or change their direction of travel unless this can be accomplished with safety and traffic is stopped by parkway personnel.
- Never permit anyone to hitchhike or solicit a ride or solicit for charity near the toll plaza. Pan handling by any person(s) is also prohibited.
- Never permit any visitors in the booth or assigned toll lane except other parkway employees or support personnel engaged in the conduct of their work.

3.5



Login to Toll Collector Touchscreen

3.5.1 Purpose

The Toll Collector Touchscreen is blank, or black, when inactive. To activate, touch the screen and the following will be displayed:

LOGIN

Insert Badge Into
Card Reader

or

Manually Login By
Entering Collector ID

ENTER COLLECTOR ID

—

1 2 3

4 5 6

7 8 9

<-- 0 Enter

3.5.2 Process

1. Either

⇒ Insert badge into card reader

Or

⇒ Key in the assigned ID number by pressing the numbers on the keypad. The entry will be displayed in the **Enter Collector ID** field.

2. Press



- The Touchscreen changes to the following:

LOGIN

Insert Badge Into Card Reader

or

Manually Login By Entering Collector ID

ENTER PIN

1 2 3

4 5 6

7 8 9

< 0 Enter

- Key in the assigned **PIN** number by pressing the numbers on the keypad. The entry will be displayed in the **Enter Collector ID** field.
- The next screen that will be displayed is the collector touchscreen.

RICKENBACHER CAUSEWAY

Perimeter Static Display

AMOUNT DUE: \$ 0.00 AMOUNT PAID: \$ 0.00 CHANGE AMOUNT: \$ 0.00

CLEAR

Perimeter Static Display

LOGOFF OPEN LANE

STATUS: LIGHT GATE

CONTINUE STANDBY

Central Changeable Display

2

ENTER PAD GATE CCTV

Perimeter Static Display

DATE/TIME:

Perimeter Static Display

DIRECTION

RECEIPT

- The outer perimeter is a static display. This has been named the **Perimeter Static Display**.

- The center of the Collector Touchscreen, however, changes if:
 - ⇒ A button is pressed in the center.

Or


- ⇒ A button is pressed in the outer perimeter.
- ⇒ This section is referred to as the **Central Changeable Display**.

3.6 Open Lane / Standby



3.6.1 Purpose

The first working Touchscreen display has three options in the Central Changeable Display:


- Open Lane
- Continue Standby
- Logoff



This section will deal only with:

-  and  that is in the Central Changeable Display.

And

-  that is located in the Perimeter Static Display.

3.6.2 Continue Standby

Continue Standby can be pressed if the Toll Collector needs a few more moments to get situated and to remove the “Lane Closed” sign or traffic cone from the lane before starting to collect tolls.



Remember, however, that after a couple of minutes, the Toll Superintendent / Plaza Shift Supervisor is notified through the Lane Monitor Screen that the Toll Collector has not opened the lane.

CONTINUE
STANDBY

1. Press
2. Remove “Lane Closed” sign or traffic cone from the lane.

3.6.3 Open Lane

OPEN
LANE

- Press . The Collector Touchscreen **Central Changeable Display** changes to allow toll collection to begin:

RICKENBACHER CAUSEWAY 2				COLLECTOR:	
CLEAR	AMOUNT DUE: \$ 0.00	AMOUNT PAID: \$ 0.00	AMOUNT CHANGE: \$ 0.00	STANDBY	
7	6	5	STATUS: LIGHT GATE	UNUSUAL OCCURRENCE	
2	3	4		DIRECTION	
	ENTER	PAD	GATE	CCTV	RECEIPT
DATE/TIME:					

3.6.4 Standby

Standby can be pressed to briefly close the lane to oncoming traffic. This action will turn the canopy light to red, but it will not close the lane, nor will it logoff the Toll Collector. Furthermore, this process will allow the Toll Collector to process the vehicles that are already in the lane.



1. Press



- The **Standby** button will change to look like this



2. Press again to revert back to **Open Lane** status.

- The **Standby** button will change back to it's original color-



3.7



Classifications 2 - 7

3.7.1 Purpose

The Toll Collector Touchscreen, when open and ready for classification, is displayed as pictured below. Vehicles with 2 to 7 axles are classified at this Toll Collector Touchscreen display.

Several procedures are addressed in this section:

- Classify (2 - 7)
- Customer Pays Exact Amount
- Customer Payment Requires Change
- Insufficient Funds



3.7.2 Classify (2 - 7)

To classify vehicles is very simple:

1. Count the axles
2. Press the button that corresponds to the number of axles

RICKENBACHER CAUSEWAY 2

COLLECTOR:

AMOUNT DUE: \$ 0.00

AMOUNT PAID: \$ 0.00

AMOUNT CHANGE: \$ 0.00

CLEAR

7 6 5

3 4

2

STATUS:

LIGHT GATE

UNUSUAL OCCURRENCE

DIRECTION

ENTER PAD GATE CCTV RECEIPT

DATE TIME:

- Press  for a 2 axle vehicle.

- Press  for a 3 axle vehicle.

- Press  for a 4 axle vehicle.

- Press  for a 5 axle vehicle.



- Press  for a 6 axle vehicle.



- Press  for a 7 axle vehicle.


Note: When a Toll Collector classifies an AVI vehicle going through the lane, they will need to press the clear button when the vehicle passes through.

3.7.3 Options

- Customer pays exact amount
- Customer payment requires change
- Customer does not have enough money

3.7.3.1 Customer Pays Exact Amount

1. Wait for the **Amount Due** button to show the toll amount




2. Customer pays the exact amount.



3. Press . The **Amount Paid** button will display.

3.7.3.2 Customer Payment Requires Change

1. Wait for the **Amount Due** button to show the toll amount




2. Customer pays with a \$ 5.00 bill.




3. Press **PAD**. The following keypad is displayed in the **Center Changeable Display**:

4. Press the numbers on the keypad and enter the amount paid.
- The amount entered will be displayed in the **Amount Paid** button like



this

- The change amount will be calculated and displayed like this



5. Give the customer the change amount as displayed in the **Amount Change** button.

3.7.3.3 If Customer Does Not Have Enough Money

See **Insufficient Funds**, section 3.9.



3.8




Classifications 8 - 15

3.8.1 Purpose

When vehicles with over 7 axles come into the toll lane, the Toll Collector must



press . This displays a set of buttons in the Central Changeable Display that can allow the Toll Collector to classify vehicles with 8 to 15 axles.

Several procedures are addressed in this section:

- Classify (8 - 15)
- Customer Pays Exact Amount
- Customer Payment Requires Change
- Insufficient Funds


3.8.2 Process

At the Touchscreen:

The screenshot shows a touchscreen interface for the Rickenbacher Causeway 2 Collector. The interface is divided into several sections:

- Top Section:** Displays "RICKENBACHER CAUSEWAY 2" and "COLLECTOR:". Below this are four boxes for "AMOUNT DUE:", "AMOUNT PAID:", and "AMOUNT CHANGE:", each showing "\$ 0.00". To the right is a "STANDBY" button.
- Middle Section:** A numeric keypad with buttons for 7, 6, 5, 3, 4, and a large button for 2. To the right of the keypad is a "STATUS:" label, a "LIGHT GATE" label, and two buttons: "UNUSUAL OCCURRENCE" and "DIRECTION".
- Bottom Section:** A row of five buttons: "ENTER", "PAD", "GATE", "CCTV", and "RECEIPT".
- Bottom Left:** A "DATE/TIME:" label.



1. Press . The following button pad is displayed in the Central Changeable Display section:

A numeric keypad with two rows of four buttons each. The buttons are labeled with the numbers 8, 9, 10, 11 in the top row and 12, 13, 14, 15 in the bottom row.

2. Press the button that corresponds to the number of axles.


Note: When a Toll Collector classifies an AVI vehicle going through the lane, they will need to press the clear button when the vehicle passes through.

3.8.3 Options

- Customer pays exact amount
- Customer payment requires change
- Customer does not have enough change

3.8.3.1 Customer Pays Exact Amount

1. Wait for the **Amount Due** button to show the toll amount




2. Customer pays the exact amount.



3. Press . The **Amount Paid** button will be displayed.

3.8.3.2 Customer Payment Requires Change

1. Wait for the **Amount Due** button to show the toll amount



2. Customer pays with a \$ 5.00 bill.



3. Press **PAD**. The following keypad is displayed in the Center Changeable Display:

RICKENBACHER CAUSEWAY 2				COLLECTOR:	
CLEAR	AMOUNT DUE: \$ 0.00	AMOUNT PAID: \$ 0.00	AMOUNT CHANGE: \$ 0.00	STANDBY	
7	ENTER AMOUNT:			STATUS:	UNUSUAL OCCURRENCE
2	1	2	3	LIGHT GATE	DIRECTION
	4	5	6		
	7	8	9		
	<-				
ENTER	PAD	GATE	CCTV	RECEIPT	
DATE/TIME:					

4. Press the numbers on the keypad and enter the amount paid.
5. The amount entered will be displayed in the **Amount Paid** button like

AMOUNT PAID:
\$ 5.00

this-

6. The change amount will be calculated and displayed like this-

AMOUNT CHANGE:
\$ 3.50

7. Give the customer the change amount as displayed in the **Amount Change** button.


3.8.3.3 If Customer Does Not Have Enough Money

See **Insufficient Funds**, section 3.9.




3.9 Insufficient Funds


1. Wait for the **Amount Due** button to show the toll amount




2. Customer pays with \$.50 .



3. Press  . The following keypad is displayed in the **Center Changeable Display**:




4. Press the numbers on the keypad and enter the amount paid.
 - The amount entered will be displayed in the **Amount Paid** button



like this-

- The amount that is still due will be calculated and displayed like this-




5. The printer will print out a receipt with **Insufficient Payment**.
6. Give the customer the receipt, stating that they owe the amount due.
7. Tell the customer that they have 48 hours to bring the receipt with the balance to the Toll Superintendent / Plaza Shift Supervisor, or a citation will be issued.
8. A VES event will occur.

3.10 Generating Receipts

3.10.1 Purpose

Very often a Customer will request a receipt for the toll paid. This can be easily



RECEIPT

generated by pressing the button.

3.10.2 Rules

- Toll payment receipts may be issued upon customer requests.
- One receipt per transaction is allowed for the amount of the toll paid.

3.10.3 Process

At the Touchscreen:

The screenshot shows a touchscreen interface for a toll collector. At the top, it reads "RICKENBACHER CAUSEWAY 2" and "COLLECTOR:". Below this, there are three columns of monetary values: "AMOUNT DUE: \$ 0.50", "AMOUNT PAID: \$ 0.00", and "AMOUNT CHANGE: \$ 0.00". To the left of these values is a "CLEAR" button. To the right is a "STANDBY" button. Below the monetary values is a numeric keypad with buttons for 7, 6, 5, 3, and 4. To the right of the keypad is a "STATUS:" label with "LIGHT" and "GATE" options. Below the keypad are buttons for "ENTER", "PAD", "GATE", "CCTV", and "RECEIPT". To the right of the "RECEIPT" button is a "DIRECTION" button. At the bottom left, there is a "DATE/TIME:" label. A large "RECEIPT" button is shown separately below the main interface.



1. Right after the payment is recorded, press
2. The Receipt Printer prints out receipt, with the plaza, date, time, lane and amount of toll paid.
3. Hand the receipt to the Customer.

3.11 Printing Out Directions

3.11.1 Purpose

At the Cross Island Parkway, the Customers often request directions for various locations. The system can now print out various locations, at the press of



, and the direction will be provided to the Customer as a public relations feature.


The Locations will be determined at a later date.

3.11.2 Process for Cross Island Parkway


At the Touchscreen:

The screenshot shows a touchscreen interface for a toll collector. At the top, it reads "RICKENBACHER CAUSEWAY 2" and "COLLECTOR:". Below this, there are four boxes for "AMOUNT DUE:", "AMOUNT PAID:", and "AMOUNT CHANGE:", each showing "\$ 0.00". To the left of these is a "CLEAR" button. To the right is a "STANDBY" button. Below the amount boxes is a "STATUS:" label, with "LIGHT GATE" below it. To the right of "STATUS:" is a button labeled "UNUSUAL OCCURRENCE". Below "STATUS:" is a "DIRECTION" button. In the center, there are buttons for "ENTER", "PAD", "GATE", "CCTV", and "RECEIPT". On the left side, there are buttons for "7", "6", "5", "3", "4", and "2". At the bottom left, there is a "DATE/TIME:" label.



1. Press .
2. The directions will be displayed in the **Central Changeable Display**.
3. The locations will be displayed in the **Central Changeable Display** and can be pressed to generate printed directions.
4. Select and press the button for the directions requested by the Customer.




5. Press . The Receipt Printer will print out the selected directions.
6. Hand directions to the Customer.

3.12 Recording Unusual Occurrences

3.12.1 Purpose

There are situations that arise within the toll collection lane that need to be



recorded. The  is pressed and the following types of unusual occurrences are recorded:

- Emergency, Police, or Maintenance Vehicles go through the lane.
- U-Turn is made by a Customer.
- A Pass is not read by the equipment and must be entered manually.
- A Customer pre-arranges payment for guests by using 'Scrip'.
- Any other strange occurrences require a 'Written' report to be made.

3.12.2 Process

At the Touchscreen:

RICKENBACHER CAUSEWAY 2

COLLECTOR:

AMOUNT DUE: \$ 0.50

AMOUNT PAID: \$ 0.00

AMOUNT CHANGE: \$ 0.00

CLEAR

7 6 5

3 4

2

ENTER PAD GATE CCTV

DATE/TIME:

STATUS:

LIGHT GATE

UNUSUAL OCCURRENCE

DIRECTION

RECEIPT



1. Press **UNUSUAL OCCURRENCE**. The following changes are displayed in the **Central Changeable Display**.

RICKENBACHER CAUSEWAY 2

COLLECTOR:

AMOUNT DUE: \$ 0.00

AMOUNT PAID: \$ 0.00

AMOUNT CHANGE: \$ 0.00

CLEAR

7

Emergency Vehicle Hunt Vehicle Replenish

Police Card/Paid

U-Turn Shop Written

2

ENTER PAD GATE CCTV


DATE/TIME:

UNUSUAL OCCURRENCE

DIRECTION

RECEIPT

2. The following options displayed in the **Central Changeable Display** can be pressed.



3. For information on **Emergency Vehicles**, press



4. For information on **Maintenance Vehicles**, press



5. For information on how to process **Replenishments**, press



6. For information on the passage of **Police** press



7. For information on how to process **Card / Pass**, press



8. For information on **U-Turns**, press



9. For information on how to process **Scrip**, press



10. For information on how to process a situation that requires a **Written**

report, press



3.12.3 Emergency Vehicles

3.12.3.1 Definition



Vehicles operating in an emergency mode, traveling at a high rate of speed, e.g.,

- Ambulances
- Fire vehicles (trucks)



This is a NON-REVENUE transaction. Money is NOT collected from this customer.

3.12.3.2 Emergency Vehicle Approaches Lane

1. Press .
2. Press .
3. A VES event will occur.

3.12.4



Maintenance Vehicles

3.12.4.1 Definition

Maintenance vehicles are those that work for the Cross island Parkway transporting maintenance personnel, equipment, and tools to and from the toll lanes.

3.12.4.2 Process



When a maintenance vehicle approaches a lane:

1. Press



2. Press



3.12.5



Police

3.12.5.1 Definition

Police vehicles operating in emergency mode, traveling at a high rate of speed can be the following:

- Marked vehicles
- Unmarked vehicles with portable light on



This is a NON-REVENUE transaction. Money is NOT collected from this customer.

3.12.5.2 Process




If emergency vehicles approach a lane (with the exception of lane 1 & 8), place the gate in the “up” position by depressing the gate button prior to their arrival. This facilitates movement through the lane and prevents accidents involving the gate arm mechanism.

1. Press



2. Press



3.12.6



Pass

3.12.6.1 Definition

When a Customer passes through the lane and the tag does not register, the Toll Collector can key in the tag number so that the Customer payment is recorded.

3.12.6.2 Process



If a Customer stops and advises the Toll Collector that the Parkway Pass does not register:

1. Press



2. Press




The following change occurs in the Center Changeable Display:

3. Enter the numbers by pressing the numbers on the keypad. If a mistake is made, press the ← key to backspace and enter the correct number.



Enter

4. Press . The gate rises automatically, and the toll amount is charged to the Customer's account.

3.12.7



U-Turn

3.12.7.1 Definition

A U-Turn will be used under two possible circumstances:

- A lost customer
- A customer that has no cash to pay for a toll.

This procedure will be registered as an 'Unusual Occurrence'.

3.12.7.2 Lost Customers



A 'lost' customer is a **NON-REVENUE** transaction. Money is **NOT** collected from this customer.



If a Customer approaches the lane and finds out that he is going in the wrong direction and needs to turn back:

1. Press



2. Press



3. Announce to all Toll Collectors by either using the intercom or blowing a whistle that there is a turnaround, and from what lane.
4. Instruct the Customer to pass through the lane, U-turn when it is safe, and return to pass through the Plaza once again.

3.12.7.3 Customers without Cash:




If a Customer approaches the lane and has no cash:

1. Press





2. Press .
3. Announce to all Toll Collectors by either using the intercom or blowing a whistle that there is a turnaround, and from what lane.
4. Instruct the Customer to pass through the lane, U-turn when it is safe. Return to pass through the far lane so as to get to the Plaza office.

3.12.8



Scrip

3.12.8.1 Definition

There will be occasions when customers will want to invite a group of guests and make arrangements with the Plaza to pay for the guests by setting up an account through the Card / Pass sales process.

The Toll Superintendent / Plaza Shift Supervisor will advise the Toll Collectors of the account # and the type of Scrip to be used.


The guests must show an invitation or some form of prearranged item that will show that they belong to the party. This is called 'Scrip'.

3.12.8.2 Process



If a Customer approaches the lane holding an invitation or some agreed upon 'Scrip' proving that they are guests:


1. Take the Scrip from the customer and press




2. Press





3. Press . The following changes will occur to the **Center Changeable Display**:



RICKENBACHER CAUSEWAY 2 COLLECTOR

AMOUNT DUE: \$ 0.00 AMOUNT PAID: \$ 0.00 AMOUNT CHANGE: \$ 0.00

CLEAR

ENTER TAG/ID:

7

1 2 3 .

4 5 6 0

7 8 9 ←

2

ENTER PAD GATE CCTV RECEIPT


DATE/TIME:

UNPAID OCCURRENCE

DIRECTION

4. Enter the account # given by the Toll Superintendent / Plaza Shift Supervisor.
5. Enter the card or tag numbers by pressing the numbers on the keypad. If a mistake is made, press the ← key to backspace and enter the correct number.



6. Press .
7. The gate will rise automatically.
8. The cost of the toll will be charged against the Customer Account.
9. Place the 'Scrip' in the Bills Revenue Bag for deposit.



If the account runs out of funds, charge the customer the toll in cash.

3.12.9



Written

3.12.9.1 Definition

Written can be used to explain any transaction that occurs, especially when a Toll Collector wants to explain any transaction circumstances. In particular, there will be occasions that an 'Unusual Occurrence' does not fit into any of the listed reasons. In these cases, a 'written' report has to be made.

3.12.9.2 Process



If an 'Unusual Occurrence' that does not fit any of the listed buttons happens:

1. Press



2. Press



- . The printer will generate a piece of paper, (similar to the receipt).
3. Write out the date, lane and a brief description of the unusual occurrence.
 4. The retained copy will be placed in the 'bills' revenue bag.
 5. Press the button to raise the gate and let the customer through.

3.12.9.3 Possible Events that Constitute an Unusual Occurrence



Bicyclists using Vehicle Travel Lanes



Counterfeit Bills

3.12.9.3.1 Rules that Govern Bicyclists using the Travel Lanes

1. Bicyclists shall be encouraged to utilize the right most lanes.
2. Bicycles set off the treadle, register as a two axle vehicle, and must be accounted for.
3. Bicycles traveling through the toll lanes must be processed as an **Unusual Occurrence Written**.
4. Bicycles are required by law to obey all traffic signs and devices. Therefore, bicyclists must stop to allow the gate arm to cycle up.

3.12.9.3.2 Rules that Govern Counterfeit Bills

- Visually inspect all bills for possible counterfeit. For bills larger than \$10, the following procedures must be followed to prevent loss of revenue:
 - ⇒ Ask the customer for a bill of a smaller denomination. If the customer questions this, explain that large bills are examined to determine that the bill is not counterfeit.
 - ⇒ Do NOT accept \$50 or \$100 dollar bills without the Toll Superintendent / Plaza Shift Supervisor's approval. If the customer has no small bills, call for the Toll Superintendent/Plaza Shift Supervisor to come to the lane.
 - ⇒ If Toll Superintendent / Plaza Shift Supervisor is unavailable, as a last resort, allow the customer to pass without paying. The transaction must be processed as an Unusual Occurrence Written.


3.13 CCTV

3.13.1 Purpose

Use CCTV in any event that the Toll Collector needs to verify his / her actions, an abusive customer, a pass not attached to a vehicle, or a robbery.


3.13.2 Process

At the Touchscreen:



The screenshot shows a touchscreen interface for a toll collector. At the top, it displays 'RICKENBACHER CAUSEWAY 2' and 'COLLECTOR:'. Below this, there are four boxes for monetary values: 'AMOUNT DUE: \$ 0.50', 'AMOUNT PAID: \$ 0.00', and 'AMOUNT CHANGE: \$ 0.00'. To the left of these is a 'CLEAR' button. To the right is a 'STANDBY' button. Below the monetary boxes is a numeric keypad with buttons for 7, 6, 5, 3, 4, and a large button labeled '2'. To the right of the numeric keypad is a 'STATUS:' section with 'LIGHT GATE' and 'UNUSUAL OCCURRENCE' buttons. Below the numeric keypad are buttons for 'ENTER', 'PAD', 'GATE', 'CCTV', and 'RECEIPT'. At the bottom left, there is a 'DATE/TIME:' label.



1. Press the  button. The system will automatically take a picture of the vehicle license tag.
2. Contact the Toll Superintendent / Plaza Shift Supervisor immediately.

3.14 Logoff Toll Collector Touchscreen

3.14.1 Purpose

At the end of a shift, the Toll Collector must logoff the system.

1. Place all scrip and written receipts in the revenue bag in which the bills are placed.
2. Remove all personal belongings from the lane.
3. Log off and close lane.

3.14.2 Process

At the Touchscreen:

RICKENBACHER CAUSEWAY 2 COLLECTOR:

	AMOUNT DUE:	AMOUNT PAID:	AMOUNT CHANGE:	
CLEAR	\$ 0.50	\$ 0.00	\$ 0.00	STANDBY
7	6	5	STATUS: LIGHT GATE	UNUSUAL OCCURRENCE
2	3	4		
	ENTER	PAD	GATE	CCTV
DATE/TIME:				




1. Press **STANDBY** that is located in the **Perimeter Static Display**. The following screen is displayed:

RICKENBACHER CAUSEWAY 2 COLLECTOR:


	AMOUNT DUE:	AMOUNT PAID:	CHANGE AMOUNT:	
CLEAR	\$ 0.00	\$ 0.00	\$ 0.00	STANDBY
7	LOGOFF	OPEN LANE	STATUS: LIGHT GATE	UNUSUAL OCCURRENCE
2	CONTINUE STANDBY			
	ENTER	PAD	GATE	CCTV
DATE/TIME:				

Continue Standby is pressed to close the lane by turning the canopy light to red and / or changing the Variable Message Sign, but allowing the Toll Collector to finish classifying the vehicles in the lane.

**CONTINUE
STANDBY**

2. Press . The Canopy Lights turn RED. Finish classifying the cars in the lane.

LOGOFF

3. Press . The Collector Touchscreen closes by turning dark.
4. Remove the badge from the card reader.
5. Place all scrip in the 'bills' revenue bag.
6. Remove all personal belongings from the toll booth.
7. Place a cone in the lane.



Remember to use the Safety Procedures in the Toll Lanes outlined in Employee Safety, section 4.4.

3.15 Deposits

3.15.1 During a Break

Return Seed Bag Deposits can be made during breaks - it is NOT necessary to wait to the end of the shift. However, revenue deposits **MUST** be made at the end of the shift.

- Prepare seed bag to turn in during first break.
⇒ It must contain \$200
- Make the seed bag deposit at the Collector Deposit Station.

3.15.2 At the End of the Shift

1. Count and place bills in a Revenue Bag.
2. Place 'Scrip' and written receipts in the Bill Revenue Bag.
3. Prepare seed bag, if it has not already been deposited at a break.
4. Follow the procedures for closing the lane. See **Logoff Toll Collector Touchscreen**, section 3.14.

3.15.3 Go to the Count Room at the Collector Deposit Station

1. Login to the **Main Application**. See **Login**, section 5.1.
2. Access the Host / Revenue & Reconciliation application. See **Application Access**, section 5.2.
3. Process deposit of Seed Bag and Revenue Bags (coin and bills). See **Deposits at Host / Revenue & Reconciliation**, section 3.16.


3.16 Deposits at Host / Revenue & Reconciliation

3.16.1 How to Access from the Collector Deposit Station

1. Login to the **Main System**. See **Login**, section 5.1.
2. Access the Host / Revenue & Reconciliation application, see **Application Access**, section 5.2.


3.16.2 Screen Displayed

The following screen is displayed:



3.16.3 Process

At the toolbar:



1. Click on
2. The following tab folder is displayed:

Collector/Clerk/Misc./Vault Deposit

Employee ID:

Revenue Bag Number:

☐ Lane Deposit
☐ Clerk Deposit
☐ Misc. Deposit
☐ Vault Deposit

Tour Of Duty Date: Choose a Date

Shift Start Time: **/**/**** **.:.

Shift End Time: **/**/**** **.:.

Tour Of Duty Duties:

☒ Bills
☐ Coins
☐ Returned Seed

Bill Counts By Denominations

Ones	0
Twos	0
Fives	0
Tens	0
Twenties	0
Fifties	0
Hundreds	0
Scripts	0 Amt. \$0.00

PayType	Counts	Amounts
<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>

Sub Total: \$0.00




Total: \$0.00

Revenue Bag Number

Revenue Bag Number	Amount

Add Save

3. The **Employee ID** field defaults to the ID of the person that logged into the system. Press **Tab**.
4. Leave Revenue Bag Number blank.
5. With the , click on the **Lane Deposit** ☒. The **Revenue Bag Number** data window will display all of the **Revenue Bag Numbers** that were assigned at the beginning of the shift to the Toll Collector making the deposit.
6. At **Tour of Duty Date**, click on the of the .

7. Highlight either yesterday or today's date, whichever is applicable. Press **Tab**. The **Shift Start Time / Shift End Time** and **Tour of Duty** fields are automatically updated. **If the Shift Start Time and Shift End Time are NOT correct, they can be changed. The Tour of Duty will be automatically updated accordingly.**
8. Click on **Bills**  to process bill deposit.
9. Click on **Coins**  to process the coin deposit.
10. Click on **Return Seed**  to process the Return Seed deposit.

3.16.3.1 Deposit Bills



If one of the bill denominations is not applicable, simply TAB to the next denomination, leaving "0" in the field.


1. Click on the **Bills** Ⓢ . The left portion of the tab folder changes to allow entry of bills.
2. At **Bill Counts By Denomination**, enter the number of **Ones**. Press **Tab**.
3. Enter the number of **Twos**, press **Tab**.
4. Enter the number of **Fives**, press **Tab**.
5. Enter the number of **Tens**, press **Tab**.
6. Enter the number of **Twenties**, press **Tab**.
7. Enter the number of **Fifties**, press **Tab**.
8. Enter the number of **Hundreds**, press **Tab**. The system will calculate the amount.
9. Enter the **Scrip** count. Press **Tab**.

3.16.3.2 Deposit Coins




If one of the coin denominations is not applicable, simply TAB to the next denomination, leaving "0" in the field.

1. Click on the **Coins** Ⓢ . The left portion of the tab folder changes to allow entry of coins.
2. At **Coin Counts By Denomination**, enter the number of **Pennies**. Press **Tab**.
3. Enter the number of **Nickels**, press **Tab**.
4. Enter the number of **Dimes**, press **Tab**.
5. Enter the number of **Quarters**, press **Tab**.
6. Enter the number of **Half-Dollars**, press **Tab**.
7. Enter the number of **Silver Dollars**, press **Tab**.
8. Enter the number **Slugs**, press **Tab**.







9. Click on the  of the **Revenue Bag Number** data window and scroll down until locating the **Revenue Bag Number** that you are using for the deposit.
10. Double click on the correct **Revenue Bag Number**. The **Revenue Bag** number will be deleted from the data window.

At the Revenue Bag Number Data Window:




1. Click on the  of the **Revenue Bag Number** data window and scroll down until locating the **Revenue Bag Number** that you are using for the deposit.
2. Double click on the correct **Revenue Bag Number**. The **Revenue Bag** number will be deleted from the data window.


3.16.3.3 Return Seed Bag


1. Click on the **Returned Seed** . The left portion of the tab folder where coin and bill denominations are entered is disabled, leaving only the **Totals** display with a **\$200.00 Returned Seed** subtotal. This amount can be modified, if different.
2. Enter **Return Seed Bag** amount at the **Subtotal** field.





3. Click on the  of the **Revenue Bag Number** data window and scroll down until locating the **Revenue Bag Number** that you are using for the deposit.
4. Double click on the correct **Revenue Bag Number**. The **Revenue Bag** number will be deleted from the data window.


At the Revenue Bag Number Data Window:




1. Click on the  of the **Revenue Bag Number** data window and scroll down until locating the **Revenue Bag Number** that you are using for the deposit.
2. Double click on the correct **Revenue Bag Number**. The **Revenue Bag** number will be deleted from the data window.

3.16.3.4 To Save After Completing Deposits - Recorded Payment Matches


1. Click on  Save .
2. The following  message is displayed:










3. Click on  . The system will calculate the number of revenue bags, a receipt for the Toll Collector, and additional copies of the receipts.
4. Put one receipt in each **Revenue Bag** and one in the **Returned Seed** bag.
5. Keep one receipt for personal records.


3.16.3.5 To Save After Completing Deposits - Recorded Payment does not Match


1. Click on  Save . The following  message is displayed:



There will only be one chance to change any of the denomination entries. If  is clicked, the data entered will be saved to the system.

2. Click on  to make changes. Since it is not known in what Revenue Bag there is a discrepancy, each revenue type must be checked.
3. Click on the **Bills**  . Recount the bag and enter any changes. See **Deposit Bills**, Section 3.16.3.1.
4. Click on the **Coins**  . Recount the bag and enter any changes. See **Deposit Coins**, 3.16.3.2.
5. Click on the **Return Seed**  . Recount the bag and enter any changes in the subtotal field. See **Return Seed Bag**, Section 3.16.3.3.
6. Click on  Save . The following  message is displayed:



7. Click on  . The system will calculate the number of revenue bags, a receipt for the Toll Collector, and additional copies of the receipts.
8. Put one receipt in each **Revenue Bag** and one in the **Returned Seed** bag.
9. Keep one receipt for personal records.

3.17 Toll Collector's Checklist

3.17.1 Policies & Regulations

1. For handling **Emergencies**, see Section 4.35.
2. To view the **Toll Collector Conduct** requirements, see Section 4.3.
3. To view what must be **Reported Immediately to the Toll Superintendent / Plaza Shift Supervisor**, see Section 4.2.
4. To view the **Pass Plans**, see Section 4.5.
5. To review **How To Approach Customers**, see Section 3.4.
6. For the policy on **Personal Items**, see Section 3.1.2.
7. For information on **What not to Ask or Permit the Customer to Do**, see Section 3.4.4.
8. For information on **Safety in Approaching the Toll Lane**, see Section 3.3.1.
9. For **General Safety Procedures**, see Section 4.4.

3.17.2 For Shift, Schedule & Break Information

1. For **Shift Information**, see Section 4.1.
2. For information on **What To Do Before Starting a shift**, see Section 3.1.
3. For information on **Parking on 7:00 - 3:00**, see Section 4.1.1.
4. For information on **Parking on 3:00 - 11:00**, see Section 4.1.2.
5. For information on **Parking on 11:00 - 7:00**, see Section 4.1.3.

3.17.3 Before Going to the Lane

1. To **Retrieve & Count Money in Seed Bag**, see Section 3.2.
2. For information on **Personal Items**, see Section 3.1.2.
3. For information on **Reviewing the Bulletin Board**, see Section 3.1.3.
4. For information on **Equipment & Uniforms**, see Section 3.1.4.
5. For information on **What Supplies are Needed at the Toll Booth**, see Section 3.1.5.

3.17.4 For Basic Information on the Toll Collector's Touchscreen

1. To login to the **Toll Collector's Touchscreen**, see Section 3.5.
2. To get information **On How The Touchscreen Display Works**, see Section 3.5.

3.17.5 For Processing Toll Collection

1. To **Open a Lane**, see Section 3.6.
2. To classify any vehicle from **Class 2 to 7**, see Section 3.7.
3. To classify any vehicle from **Class 8 to 15**, see Section 3.8.
4. To provide a customer with a **Receipt**, see Section 3.10.
5. To provide **Change To A Customer That Does Not Give Exact Amount**, see Section 3.7.4. and 3.8.4.
6. To review the procedure to **Logoff and Close a Lane**, see Section 3.15.7.
7. To access the **Host / Revenue & Reconciliation** application, see Section 5.2.3.
8. To make a **Deposit**, see Section 3.15.

3.17.6 For Special Situations

1. To provide **Change To A Customer That Does Not Give Exact Amount**, see Section 3.7.3.2 and 3.8.3.2.
2. To handle an **Insufficient Funds** customer, see Section 3.9.
3. To process a **Bicyclist** that goes through a travel lane, see Section 3.12.9.3.1.
4. To process **Emergency Vehicles**, see Section 3.12.3.
5. To process **Police**, see Section 3.12.5.
6. To handle **Lost Customers**, see Section 3.12.7.2.
7. To handle **Customers without cash**, see Section 3.12.7.3.
8. To process a **Maintenance Vehicle**, see Section 3.12.4.
9. To process **Scrip**, see Section 3.12.8
10. For information on how and when to use the **CCTV**, see Section 3.13.

4. Policies & Regulations

4.1 Shift Information

4.1.1 7:00 AM - 3:00 PM Shift

4.1.1.1 Break / Meal by Lane

Lanes and corresponding break times will be determined at a later date.

Lane	Break #1	Meal	Break #2
------	----------	------	----------

4.1.1.2 Break Information

Toll Collectors are on a straight eight-hour-a-day shift.

- Meals are eaten on LMIMS time; thus, meal periods will be brief.
- If the meal period exceeds 15 minutes, it will be considered excessive.
- Two 15-minute breaks per eight-hour shift will be allowed.
- The two breaks cannot be combined either together or with the meal period.
- Obtain the Toll Superintendent / Plaza Shift Supervisor's approval prior to leaving an assigned tollbooth for a rest room break.

4.1.1.3



Break Room Regulations


- Employees are required to use the break room for meals. Desk / work areas are not to be used.
- Any food brought to the toll plaza should be labeled and placed in the refrigerator.
- Employees should respect the food and drink of others that are stored in the refrigerator.
- Employees are expected to clean up after themselves and throw old food away.
- Refrigerator clean-outs will be performed periodically. Any food and / or dirty dishes left after a shift will be disposed of.

4.1.1.4



Parking

- Park personal vehicles in the parking lot adjacent to the Operations Building.
- Bring all items required during shift into the office as the parking lot is off limits during a shift.
- If extraordinary circumstances warrant entering the parking area or a personal vehicle, the Toll Superintendent / Plaza Shift Supervisor must accompany the Toll Collector.



4.1.2



3:00 PM - 11:00 PM Shift

4.1.2.1



Break / Meal by Lane

Lanes and corresponding break times will be determined at a later date.

Lane	Break #1	Meal	Break #2
------	----------	------	----------

4.1.2.2



Break Information

Toll Collectors are on a straight eight-hour-a-day shift.

- Meals are eaten on LMIMS time; thus meal periods will be brief.
- If the meal period exceeds 15 minutes, it will be considered excessive.
- Two 15-minute breaks per eight-hour shift will be allowed.
- The two breaks cannot be combined either together or with the meal period.
- To leave an assigned tollbooth for a rest room break, obtain the Toll Superintendent / Plaza Shift Supervisor's approval prior to leaving.

4.1.2.3



Break Room Regulations

- Employees are required to use the break room for meals. Desk / work areas are not to be used.
- Any food brought to the toll plaza should be labeled and placed in the refrigerator.
- Employees should respect the food and drink of others that are stored in the refrigerator.
- Employees are expected to clean up after themselves and throw old food away.
- Refrigerator clean-outs will be performed periodically. Any food and / or dirty dishes left after a shift will be disposed of.



4.1.2.4



Parking

- Park personal vehicles in the parking lot adjacent to the Operations Building.
- Bring all items required during shift into the office as the parking lot is off limits during a shift.
- If extraordinary circumstances warrant entering the parking area or a personal vehicle, the Toll Superintendent / Plaza Shift Supervisor must accompany Toll Collector.



4.1.3



11:00 PM - 7:00 AM Shift

4.1.3.1



Break / Meal by Lane

Lanes and corresponding break times will be determined at a later date.

Lane	Break #1	Meal	Break #2
------	----------	------	----------

The number of Toll collectors for the 11:00 PM - 7:00 AM will be determined.

4.1.3.2



Break Information

Toll Collectors are on a straight eight-hour-a-day shift.


- Meals are eaten on LMIMS time; thus, meal periods will be brief.
- If the meal period exceeds 15 minutes, it will be considered excessive.
- Two 15-minute breaks per eight-hour shift will be allowed.
- The two breaks cannot be combined either together or with the meal period.
- To leave an assigned tollbooth for a rest room break, obtain the Toll Superintendent / Plaza Shift Supervisor's approval prior to leaving.

4.1.3.3



Break Room Regulations

- Employees are required to use the break room for meals. Desk / work areas are not to be used.
- Any food brought to the toll plaza should be labeled and placed in the refrigerator.
- Employees should respect the food and drink of others that are stored in the refrigerator.
- Employees are expected to clean up after themselves and throw old food away.
- Refrigerator clean-outs will be performed periodically. Any food and / or dirty dishes left after a shift will be disposed of.




4.1.3.4



Parking

- Park personal vehicles in the parking lot adjacent to the Operations Building.
- Bring all items required during shift into the office as the parking lot is off limits during a shift.
- If extraordinary circumstances warrant entering the parking area or a personal vehicle, the Toll Superintendent / Plaza Shift Supervisor must accompany Toll Collector.



4.2 Immediately Notify Toll Superintendent / Plaza Shift Supervisor

4.2.1 To Report Equipment not Working Properly

- Report any equipment problems to the Toll Superintendent / Plaza Shift Supervisor immediately.
- Toll Collectors are not permitted to perform any adjustments or repairs to equipment.

4.2.2 To Report Accidents

All accidents or incidents must be reported to the Toll Superintendent / Plaza Shift Supervisor on duty.

4.2.3 Prior to Leaving the Booth

- Obtain the Toll Superintendent / Plaza Shift Supervisor's approval prior to leaving an assigned tollbooth for a rest room break.
- When tollbooth is unattended, the Toll Collector is responsible for the accuracy and contents of the seed and revenue bags.

4.2.4 To Report Emergencies

The procedures for reporting emergencies and telephone usage will be determined.

4.2.5 To Report Counterfeit Bills

- Toll Collectors should visually inspect all bills for possible counterfeit. For bills larger than \$10, the following procedures must be followed to prevent loss of revenue:
 - ⇒ Ask the customer for a bill of a smaller denomination.

- ⇒ If the customer questions this, explain that large bills are examined to determine that the bill is not counterfeit.
- ⇒ Do NOT accept \$50 or \$100 bills without the Toll Superintendent / Plaza Shift Supervisor's approval.
- ⇒ If the customer has no small bills, send customer to the office and notify the Toll Superintendent / Plaza Shift Supervisor.
- ⇒ If Toll Superintendent / Plaza Shift Supervisor is unavailable, as a last resort, allow the customer to pass without paying. This will be recorded as an Unusual Occurrence - Written. See **Written**, Section 3.12.9.

4.2.6 To Report Change Left by a Customer

Submit change left by customer to the Toll Superintendent / Plaza Shift Supervisor.

For each instance:

- Report the incident to the Toll Superintendent / Plaza Shift Supervisor using the Cross Island Parkway Unusual Occurrence / Exception Report.
- Indicate the time of the incident.
- Detail the type of vehicle (make, model, color).
- Provide Toll Superintendent / Plaza Shift Supervisor exact amount of change not received by the customer.

4.3



Toll Collector Conduct

4.3.1



Conduct with Others

Use good judgment and always be professional.

4.3.2



Personal Hygiene

- Hands need to be washed thoroughly with soap and water at the beginning of each relief period, before eating or drinking, and again at the end of a shift. Currency and coins are often dirty or contaminated after being handled by countless numbers of people.
- Keep the rest room and break room facilities clean and free from uneaten food, unwashed food containers, dishes and cooking utensils.
- Use break room garbage cans for all food and meal-related trash.

4.3.3



Plaza Equipment

- Do not use office equipment without Toll Superintendent / Plaza Shift Supervisor authorization. This includes fax machines, credit card authorization / printing units, typewriters, copy machines, and computers.
- Do not place seed bags, food, beverages, or other items on the machines so as to avoid damage.

4.3.4



Tardiness and Absenteeism

- If sick or tardy, contact the Toll Superintendent / Plaza Shift Supervisor one hour PRIOR to the start of shift to allow for replacement coverage.
- Unauthorized absences will be given if an employee does not call at least 15 minutes prior to the start of the shift.

4.3.5



Personal Phone Calls

- Except in the case of emergency, incoming phone calls may not be accepted.
- If an emergency arises, the caller must explain to the Toll Superintendent / Plaza Shift Supervisor the nature of the emergency, who will in turn inform the Toll Collector.
- Toll Collector must return the call during the next break using the telephone in the break room.

4.3.6



Smoking

Smoking is prohibited in the:


- Tollbooths
- Employee break room
- Administrative building

4.3.7



Operation of an LMIMS Vehicle

- A Toll Collector maybe required to drive an LMIMS Vehicle.
- Check the assigned vehicle for any signs of damage.
- Report damage detected or repairs needed to the Toll Superintendent / Plaza Shift Supervisor.
- All employees operating County vehicles are required to possess a valid State of South Carolina driver's license.
- All drivers must wear seat belts and obey South Carolina traffic laws.
- If involved in a vehicular accident while on duty, report the accident to the Beaufort County Sheriff's Department as well as the Toll Superintendent / Plaza Shift Supervisor.



4.4



Employee Safety

To minimize occasions where employees could be injured or the State or LMIMS could be liable in the event of an injury to a customer or damage to their property, the following rules will be adhered to:

4.4.1 Customers in the Lane

- Never open the door of any vehicle except in the case of an emergency.
- Never request the driver of a vehicle to push or tow another vehicle.
- Never request customers to get out of their vehicle to retrieve any object, including toll payment, which may have fallen or dropped into the toll plaza area.
- Always make a reasonable effort to prevent customers from getting out of their car while the vehicle is stopped in the lane.
- Never direct drivers to stop their car or change their direction of travel, unless this can be accomplished with safety and traffic is stopped by parkway personnel.
- Never detain the driver or any vehicle in an effort to enforce the law unless:
 - ⇒ The driver of the vehicle or the load being hauled is a potential hazard to other parkway customers or can possibly cause damage to County property.
 - ⇒ The law pertinent to the use of vehicular crossings is being violated in regard to vehicle type and size, or the vehicle consists of material which is prohibited or restricted on the parkway.
 - ⇒ A manager instructs a toll collector to detain a particular vehicle.
- Never permit anyone to hitchhike or solicit a ride or solicit for charity near the toll plaza. Pan handling by any person(s) is also prohibited.
- Never permit any visitors in your booth or assigned toll lane except other parkway employees or support personnel engaged in the conduct of their work.



4.4.2 Toll Collectors

- Never run across the lanes or about the Toll Plaza office.
- Make every reasonable effort to avoid stepping in the grease and oil deposited by vehicles passing through the toll plaza.
- Never cross in front of a closely approaching or stopped vehicle, unless the driver is aware of the intention to do so. The driver of the vehicle in front may inadvertently place the car in reverse and someone may be seriously injured.
- Always be in a position of readiness as a vehicle approaches the assigned toll lane. In the event the driver loses control, the Toll Collector may then be in a better position to move back in the booth for safety.
- If required to walk in either direction between the tollbooth and a vehicle stopped in the lane, never step off the curb unless facing approaching traffic.
- Always be certain that no body parts project over the curb in the assigned toll lane when traffic is approaching.
- Never make an attempt to collect a toll from a vehicle that is moving.
- Never attempt to reach inside a moving vehicle or walk alongside a moving vehicle, especially a truck or bus.
- If a holdup occurs, **NEVER** offer any resistance.

4.5



Pass Plans

4.5.1 Cross Island Parkway Toll Plaza Plans

Actual fees will be determined at a later date.

4.5.1.1 Cash

- Collect cash payment in toll lane
- No discounts apply

Cash Fees:


AXLE(s)	COST
2 axle	\$ 0.625/axle
3 axle	\$ 1.50/axle
4 axle	\$ 1.75/axle
5+axles	\$ 1.80/axle

4.5.1.2 Parkway Card Plan

- Residents
- Available to non-residents, non-revenue or commercial accounts
- Discounted from cash

Cash Fees:

AXLE(s)	COST
2 axle	\$ 0.50/axle
3 axle	\$ 1.00/axle
4 axle	\$ 1.25/axle
5+axles	\$ 1.50/axle



4.5.1.3 Commuter Card / Pass Plan

Commuter Card / Pass Available to

- Persons employed on the island
- Students attending a school in Key Biscayne
- A parent driving a student to a school in Key Biscayne

Required Documentation

- Proof of employment on island for a minimum of 32 hours per week
- Letter from employer or pay stub
- Letter from school
- Copy of current school registration

Commuter Card / Pass Fees

- | | |
|---|----------------------|
| • Commuter Card / Pass Fee
⇒ 2-axle vehicle only | \$0.11/axle |
| • Parkway Pass Deposit | \$20.00 each Pass |
| • Parkway Card Deposit | \$3.00 each Card |
| • Lost Parkway Pass
⇒ (Internal Transponder) Fee | \$33.00 each Pass |
| • Lost Parkway Pass
⇒ (External Transponder) Fee | \$43.00 each Pass |
| • Lost Parkway Card Fee | \$3.00 each Card |
| • Parkway Card / Pass Transfer | \$5.00 each transfer |
| • Monthly Statement Fee | \$3.00 |
| • Individual Card / Pass Account
Replenishment | \$25.00 |
| • Commercial Card/Pass Account
Replenishment | \$100.00 |

4.5.1.4 Resident Card / Pass Plan

- Obtain proof that the customer is a Key Biscayne resident:
 - ⇒ A current utility bill
 - ⇒ Vehicle registration, vehicle lease agreement, or car rental document
 - ⇒ Make copies of the above and return originals to the customer

4.5.1.5 Resident Card / Pass Fees

- Resident Card / Pass Fee \$0.06/axle
2-axle vehicle only
- Lost Parkway Pass
 - ⇒ (Internal Transponder) Fee \$33.00 each Pass
- Lost Parkway Pass
 - ⇒ (External Transponder) Fee \$43.00 each Pass
- Parkway Card / Pass Transfer \$5.00 each transfer
- Monthly Statement Fee \$3.00
- Individual Card/Pass Account
Replenishment \$25.00

4.6 Tollbooth Operation

This section describes the procedures followed by the Toll Collector to open, operate, and close a manual toll lane. Also, this section describes the equipment required for the proper operation of a lane, the safety and security inspection to be conducted, and the method of reporting irregularities.

4.7 Equipment Needed

At the start of the shift and before opening a toll lane, the Toll Collector must possess the following equipment:

- Toll collector change fund
- Toll collector Key Identifier Card
- Cash drawer, key
- Toll collector nameplate
- Revenue bags
- Variety of forms for documenting activities during the shift (i.e., Palmetto Pass Applications, Cross Island Parkway Unusual Occurrence & Exception Report Forms, etc.)
- Safety vest

4.7.1 Toll Collector Change Fund

The Toll Collector's change fund is issued to the Toll Collector for the purpose of providing change to patrons using the Cross Island Parkway. Each incoming Toll Collector receives a change fund from the previous Toll Collector, or the Plaza Shift Supervisor, if the Toll Collector is not present.

- The change fund remains a constant amount and is distinct from the daily revenue collections.
- The denominations of bills and coins are dependent upon the location of the collection point.
- The change fund is verified by use of the Cash Exchange / Transfer Report, which is completed by the person issuing the fund and signed by both the issuer and the receiver of the fund.
- At the end of the shift, the Toll Collector returns the change fund to the Plaza Shift Supervisor who verifies and signs for the fund on the Cash Exchange / Transfer Report and places the fund into the on-site safe.
- The Toll Collector is responsible and accountable at all times for all funds under their control.
- Personal funds are not to be brought to the lane and should be kept in the Toll Collector's personal locker.

4.7.2 Toll Collector Key Identifier Card

Each Toll Collector is issued one card with their own distinct PIN. The card is approximately 2 inches by 3-1/4 inches and is used as follows:

- Once inside the tollbooth, the Toll Collector slides their Key Identifier Card through the card reader located near the Manual Lane Terminal (MLT).
- The MLT prompts the Toll Collector to enter the PIN.

4.7.3 Toll Collector Cash Drawer

Cash drawers are provided and used as follows:

- Cash drawers are provided in each tollbooth.
- The Toll Collector assigned to collect tolls uses the top drawer to hold the toll revenue.
- The toll revenue is kept in a neat and orderly arrangement in the cash drawer.
- The cash drawer is kept locked whenever the Toll Collector is absent from their post, with the key staying in the possession of the Toll Collector during any such absence.
- When the cash drawers are in use and are unlocked, the keys must be kept in their locks.
- When the drawers are not in use, they must be locked, and the keys returned to the Plaza Shift Supervisor.
- It may be necessary during or immediately after peak traffic hours to turn over partial revenue collections to the Plaza Shift Supervisor.

4.7.4 Toll Collector Nameplate and Badge

Each Toll Collector is issued a nameplate and badge.

4.7.5 Revenue Bag

- The Toll Collector is assigned a Revenue bag at the start of each shift.
- At the end of the shift, the Toll Collector places his collections in the Revenue bag and deposits them into the on-site safe in the utility building, or at the mainline operations, or satellite building.

4.7.6 Forms

The following forms may be required during the shift and are kept in each tollbooth.

- Cross Island Parkway Shift Incident Report
- Cross Island Parkway Patron Complaint Form
- Cross Island Parkway Unusual Occurrence & Exception Report Form
- Suspect Description Form
- Cash Exchange/Transfer Report
- Ad Hoc Toll Collection Report

If the forms are not readily available in the tollbooth, the Toll Collector notifies the Plaza Shift Supervisor immediately.

4.8 Opening the Toll Lane

Before a Toll Collector opens a toll lane, a series of inspections is required. These required inspections are described in the following sections.

4.8.1 Security Inspection

The Toll Collector arriving on duty:

- Conducts a security inspection of the tollbooth and toll lane area to ensure the preceding Toll Collector has left no toll revenue or personal equipment.
- Checks the cash drawer, front and rear counters, windowsills, and floor for any cash. Any cash found must be kept separate from tolls collected during the shift and turned into the Plaza Shift Supervisor. The Plaza Shift Supervisor documents and deposits this money on the Supplemental Revenue Sheet.

4.8.2 Tollbooth / Lane Inspection

The Toll Collector:

- Checks locking mechanisms, doors, glass, lights, MLT, receipt printer, cash drawer, and cash tray in the booth and lane to determine that their physical and operating conditions are satisfactory.
- Notifies the Plaza Shift Supervisor at once if any item is not in proper condition. The Plaza Shift Supervisor notes any discrepancy on the Cross Island Parkway Shift Incident Report

4.8.3 Safety Inspection

The Toll Collector:

- Conducts an inspection to determine any unsafe conditions. Unsafe conditions include the presence of a heavy accumulation of oil or grease in the toll lane, roadway or walkways, or any condition including unsafe wiring and safety equipment malfunction which may cause injury to personnel or damage to equipment.
- Notifies the Plaza Shift Supervisor immediately of any unsafe conditions or malfunctioning equipment. The Plaza Shift Supervisor notes any discrepancy on the Cross Island Parkway Shift Incident Report

4.8.4 Supply Inspection

The Toll Collector ensures that tollbooths contain an adequate quantity of supplies as listed below:

- Rubber bands
- Paper clips
- Tape
- Pens
- Manually-issued toll receipts
- Palmetto Pass business cards and applications
- Toll road maps
- Forms

The Toll Collector reports low or missing supplies to the Plaza Shift Supervisor.

4.9 Operating a Manually Attended Toll Lane

4.9.1 Logging On

The Toll Collector:

- Completes all inspections as described in Sections 4.8.1 through 4.8.4.
- Logs onto the MLT in the tollbooth. This allows the customer to pay the Toll Collector or use the AVI.
- At the time of log on, should ensure the printer is operational, and the MLT shows "Printer - ON" and "Paper - OK."

4.9.2 Position for Collecting Tolls

The Toll Collector:

- Makes collections from a standing or sitting position at all times.
- Stands or sits at the doorway of the tollbooth, always behind the lower portion of the double door, while engaged in transactions with patrons.

4.10 Classifying Vehicles

SCDOT has established standard vehicle classifications with appropriate fees for various types of vehicles likely to use the Cross Island Parkway.

4.10.1 Vehicle Classification Chart

Toll collectors classify each vehicle in accordance with the Vehicle Classification Chart and register the proper classification into the MLT.

4.10.2 Island Traffic Signal

Once the vehicle has been classified, the toll collected, and the vehicle committed, the island traffic signal changes from red to green.

- When the island traffic turns green, the customer exits the lane.
- If the island traffic signal is not functioning properly, the Toll Collector advises the customer to go ahead and exit the lane anyway.
- The Toll Collector immediately notifies the Plaza Shift Supervisor to report the malfunctioning traffic light and makes a note on the Cross Island Parkway Unusual Occurrence & Exception Report Form.

4.11 Making Change

- The Toll Collector clearly states the amount of change, if any, to the customer in order to avoid misunderstanding.
- When currency is received, it is weighted on the counter in full view, and not placed in the cash drawer until the change has been made and accepted by the customer.
- If a patron pays the toll with rolled coins, the Toll Collector must accept the payment, but opens the coin wrapper before the patron leaves the toll lane to inspect the coins to make sure there is no foreign currency or slugs.
- If foreign currency or slugs are found in the rolled coins, the Toll Collector requests the patron to pay the correct toll. If the patron refuses to pay the toll, the Toll Collector records the transaction as a violation.
- If the Toll Collector is accustomed to holding change for a single dollar, it is never handed to the customer as change when the tendered amount is \$2.00 or more. The Toll Collector holds the change and secures the proper balance of change required, then turns to the customer, counts the money as prescribed, and hands the entire amount to the customer. The Toll Collector includes a receipt, if requested.
- Inspects bills to ensure that \$10 bill corners have not been put on corners of \$1 bills to alter the amount.
- If a customer arrives at the plaza and immediately engages in conversation, the Toll Collector courteously makes an excuse to end the conversation, requests the toll, and completes the toll transaction. After this transaction is completed, questions may be answered. This prevents confusion or arguments as to whether or not the toll payment has been made.
- The Toll Collector watches for shortages of any cash or coin denominations in the cash drawer and notifies the Plaza Shift Supervisor in sufficient time to bring additional cash or coin denominations to make change. Use the Cash Exchange / Transfer Report to exchange currency and/or coins with the Plaza Shift Supervisor.

4.12 Cash Accumulation

To keep from accumulating large amounts of cash, the Toll Collector turns in excess cash to the Plaza Shift Supervisor as follows:

- Bundles bills to be turned in as stacks of \$200
- Notifies the Plaza Shift Supervisor when excess cash needs to be turned in
- Completes a Cash Exchange / Transfer Report and has the Plaza Shift Supervisor sign for the cash being turned in.

At the end of each shift, the Plaza Shift Supervisor on duty returns the bundles of cash to the respective Toll Collector for inclusion in the Toll Collector's close-out or end-of-shift procedures.

4.13 Unacceptable Payments

The Toll Collector does not accept:

- Personal checks
- Travelers' checks
- Foreign currency or non-monetary forms of payment, i.e., watches, rings, etc.
- Payment of tolls for previous violations or transactions at other lanes.
Advises customers their vehicle license plate was photographed at the location where the violation occurred and they will be notified by mail of the toll amount due
- Transponders being dropped off by patrons
- Violation payments
- Any partial payments
- Credit cards

4.14 Receipts to the Public

The Toll Collector:

- Provides a properly printed receipt for cash toll collected from the driver of a vehicle, upon request, at the time of toll payment
- Honors a receipt request obligingly and without comment. Never issues a receipt for any alleged previous passage, and / or for any other lane
- In the event that the printer is incapacitated, the Toll Collector will fill-out and issue the Manual Toll Receipt.

4.15 Directions to Motorists

Procedures for directions to motorists are described in section 3.11.



4.16 Counterfeit Money

Since Toll Collectors are responsible for all revenue collected, it is imperative that each Toll Collector have a thorough knowledge of methods for detecting counterfeit money and knows the procedure to be followed in the event that a customer submits a payment of counterfeit money.

4.16.1 Identification Of Counterfeit Bills

A close examination is the most reliable method of detecting counterfeit bills or coins. In the case of bills, the following steps are provided to assist the Toll Collector in establishing the authenticity of money offered in payment of tolls.

- Compare sizes of bill - Counterfeits are rarely the same size as genuine bills.
- Examine portrait - Especially around the pupils of the eyes, which are usually indistinct on counterfeit bills.
- Compare engraved border and green coloring with a genuine bill. The borders on the face and back plates of every bill are executed in minute detail with lathe or scrollwork. Outstanding characteristics are complete continuity and uniformity of shading. Most counterfeits are lacking in these respects.
- Check with any "alert lists" that may be available.

4.16.2 Acceptance Of Counterfeit Money

In the event that a Toll Collector feels the customer has become confrontational, they should accept counterfeit money. The follow-up procedures are:

- When a Toll Collector believes a bill or coin received for tolls is counterfeit, they note the vehicle description and license plate number and immediately notify the Plaza Shift Supervisor.
- The Plaza Shift Supervisor notifies the Toll Superintendent, and the bill is held for police or other authorized personnel.
- The Toll Collector submits a Cross Island Parkway Unusual Occurrence & Exception Report Form describing the incident.
- The Toll Collector fills out the Suspect Description Form.

4.16.3 Customer Counterfeit Change Claim

If the customer claims that change returned upon payment of a toll was given in the form of counterfeit, mutilated, or foreign money, and if the customer has just paid the toll and the claim appears immediately to be an honest one, the Toll Collector performs the following:

- Promptly retrieves the defective or otherwise apparently unacceptable money and issue change in official United States currency
- Holds the alleged invalid money returned by the customer out of deposit for police or other authorized personnel and records the incident on the Cross Island Parkway Unusual Occurrence & Exception Report Form
- Makes a full report to the Plaza Shift Supervisor

4.17 Short-Change Complaints

Toll collectors are required to follow these steps each time a short-change complaint is received:

- When a customer, who has not yet left the toll lane, claims to have been short-changed, and the Toll Collector is certain the claim is justified, the claim is paid in the proper amount.
- If the customer claim is doubtful, the Toll Collector does not make a payment. If the customer has not left the lane, the Toll Collector fills out the Cross Island Parkway Patron Complaint Form and indicates that the Plaza Shift Supervisor will investigate and follow-up once the cash drawer has been balanced at the end of the shift.
- If a customer departs from a toll lane without receiving the proper change, the Toll Collector records the vehicle license number and immediately notifies the Plaza Shift Supervisor. The Toll Collector includes the overpayment with the daily deposit and submits a Cross Island Parkway Unusual Occurrence & Exception Report Form.
- When a customer informs a Toll Collector of being short-changed at a different toll plaza, ramp, or during a different Toll Collector's shift, the Toll Collector makes out a Cross Island Parkway Patron Complaint Form and informs the customer the Plaza Shift Supervisor will follow up.
- When a customer telephones a short-change complaint to the Operations office, the employee receiving the call fills out the Cross Island Parkway Patron Complaint Form. The supervisor receiving the call prints the complainant's name on the line normally signed by the complainant. The notation "received via telephone" should appear under the printed name.

4.18 Reported Overpayment

When a customer notifies a Toll Collector of receiving an overpayment, the Toll Collector performs the following:

- Accepts the money and gives the customer a receipt noting, this fact on the back.
- Fills out a Cross Island Parkway Unusual Occurrence & Exception Report Form and turns the money over to the Plaza Shift Supervisor who makes a separate deposit of the money using the Supplemental Revenue Sheet.

NOTE: If an overpayment is reported directly to a Plaza Shift Supervisor, the same procedure as above is followed, and a separate deposit is made.

4.19 Operating a Manually Attended Toll Lane with ACM or AVI Capability

4.19.1 Logging On To The Lane

Toll Collectors use their Key Identifier Card to log onto the MLT.

4.19.2 AVI Customers

The island traffic light is red as each new vehicle approaches, notifying the customer to stop.

- AVI lanes are operational at all times with the manually attended tollbooth. The MLT recognizes an AVI customer as the customer enters the lane. The vehicle appears on the MLT as the letter "A."
- If an AVI customer stops at the booth and wants to manually pay the toll, the toll vehicle classification / collections process is the same for any other vehicle.
- If the Toll Collector observes the MLT is not picking up the AVI customer or the island traffic light is not changing from red to green, the Toll Collector immediately calls the Plaza Shift Supervisor and makes a note on the Cross Island Parkway Unusual Occurrence & Exception Report Form. The Toll Collector does not close the lane.

4.20 Closing a Toll Lane

Lanes must not be closed or cones placed in the lane without direct authorization from the Plaza Shift Supervisor. This rule applies to both plaza and ramp operation.

The Toll Collector complies with the following procedures for closing a lane for meal or break periods and at the completion of a shift.

4.20.1 Closing a Lane for Meal or Break Periods

Before leaving the tollbooth for any meal or break, the Toll Collector:

- Prepares seed bag deposit as required
- Presses the STANDBY button on the MLT to change the canopy light from green to red
- Places two cones below the canopy light at the entrance to the lane when the lane is clear of traffic
- Completes the MLT log off procedure
- Places the nameplate in the cash drawer and takes the Key Identifier Card
- Secures all cash collections in the cash drawer
- If using a cash tray, locks the lid in place. The key to the lid is kept in the Toll Collector's possession.
- If using the cash drawer, locks the cash drawer. The cash drawer key is kept in the Toll Collector's possession.

4.20.2 Closing a Lane at the End of a Shift

At the end of the Toll Collector's shift, the Toll Collector performs the following steps to close the lane:

- Presses the STANDBY button on the MLT to change the canopy light from green to red
- Places two cones below the canopy light at the entrance to the lane when the lane is clear of traffic
- Completes the MLT log off procedure
- Removes the nameplate, totals collections and the shift change fund
- Places all completed forms and monies from the shift in the Revenue bag for deposit in the on-site safe. Leaves the cash drawer key in the cash drawer for the Toll Collector arriving on duty.

- Cleans the counter top and tollbooth of loose debris, depositing same in the waste receptacles provided
- Closes the tollbooth's door and verifies it is locked

4.20.3 Direct Relief

If a Toll Collector is directly relieved by another Toll Collector or Plaza Shift Supervisor, traffic is momentarily stopped at the booth by the relieving person, while the changeover is being made. The changeover must be made within 60 seconds.

- The Toll Collector being relieved of duty:
 - ⇒ Presses the STANDBY button on the MLT to change the canopy light from green to red
 - ⇒ Completes the MLT log off procedure
 - ⇒ Removes their nameplate, adds collection and shift change funds
 - ⇒ Places all completed forms and monies for the shift in the Revenue bag for deposit in the on-site safe. Leaves the cash drawer key in the cash drawer for the Toll Collector arriving on duty
 - ⇒ Cleans the counter top and tollbooth of loose debris, depositing same in the waste receptacles provided
- The Toll Collector arriving on duty:
 - ⇒ Logs onto the MLT
 - ⇒ Performs the procedures described in section 4.8, as required, and when traffic allows
 - ⇒ Places the change fund in the cash drawer

4.21 Ad Hoc Collections - Equipment Malfunctions

See Section 4.40.

4.21.1 The Toll Collector performs the following steps:

- Notifies the Plaza Shift Supervisor or system operator immediately of equipment malfunctions. The Plaza Shift Supervisor makes the determination if the lane should be closed (coned off) or if ad hoc traffic collection is to be performed.
 - ⇒ If the lane is to be coned off, follow standard lane closure procedures.
 - ⇒ If ad hoc toll collection is to be performed, continue with the following steps.
- Notes on the Cross Island Parkway Unusual Occurrence & Exception Report Form the time the malfunction occurred and when it was corrected
- Records the number and class of vehicles being processed on the Ad Hoc Toll Collection Report. This information is forwarded to the Account Clerk to aid in reconciliation
- Resumes normal toll collection when the malfunction has been corrected
- Places ad hoc toll collection funds and the Ad Hoc Toll Collection Report in a separate Revenue bag provided by the Plaza Shift Supervisor. These are kept separate from all other funds.
- Locks the Revenue bag. The Toll Collector keeps the Revenue bag key.
- Keeps the Revenue bag in the tollbooth until the end of the shift.
- Deposits the Revenue bag(s) into the on-site safe at the end of the shift. The Plaza Shift Supervisor must witness the deposit of the Revenue bag(s) into the on-site safe, and both the Toll Collector and the Plaza Shift Supervisor must sign the Deposit/Transfer Log.

4.22 Closing Out At The End Of A Shift

The Toll Collector:

- Removes the change fund in accordance with Section 4.2.1
- Stacks all bills by denominations (\$1, \$5, \$10, etc.) in a uniform manner. Stacks the denominations face up, with bills facing in the same direction. Secures stacks with rubber bands. Places all currency in the Revenue bag.
- Places coins in the Revenue bag
- Places the original Cross Island Parkway Unusual Occurrence & Exception Report Form in the Revenue bag, if applicable
- Seals the Revenue bag

The Plaza Shift Supervisor:

- Unlocks and opens the on-site safe
- Witnesses the Revenue bag drop and signs the Deposit / Transfer Log

The Toll Collector:

- Drops the sealed Revenue bag into the on-site safe
- Signs the Deposit/Transfer Log

4.23 Outside Employment

CIP personnel are permitted to accept outside employment or activities unless such activities in any way hold preeminence over CIP toll road operations, involve conflicts of interest, or prevent the performance of duties on behalf of Lockheed Martin IMS.

4.24 Standards of Conduct

4.24.1 All CIP Personnel

- Will conduct themselves in a manner that reflects favorably upon the good name and reputation of SCDOT and Lockheed Martin IMS
- Are prohibited from the use of or trafficking in narcotics or any other controlled substance. Violators may be subject to immediate dismissal.
- Are prohibited from consumption or possession of alcoholic beverages on SCDOT property. Employees reporting to work under the influence or emitting pronounced odor of intoxicating beverages are not permitted to work and may be subject to disciplinary action.
- Are prohibited from engaging in games of chance or in the sale or purchase of raffle, lottery, or sweepstakes tickets or any other form of gambling on SCDOT property
- Are prohibited from soliciting funds for any charity or other causes on SCDOT property with prior authorization from the Toll Operations Manager
- Are prohibited from the possession or handling of weapons on SCDOT property, including parking areas
- Are prohibited from chewing tobacco while on duty. Smoking is prohibited except in designated smoking areas.
- Are required to report any change of address or telephone number within 48 hours to their immediate supervisor and the IMS Human Resources office

4.24.2 Specific to Toll Collection Personnel

- Are prohibited from accepting gifts, tips, or any article of value from customers in payment for personal services or as a pledge of payment for tolls while on duty
- Are prohibited from purchasing property or services of any kind from a driver or occupant of any vehicle using the CIP while on duty
- Are prohibited from soliciting rides for or from customers using the CIP while on duty

4.25 Training and Appraisals

4.25.1 Training

- The Toll Superintendent is responsible for ensuring that all CIP personnel have received the complete and proper training to prepare for manual toll collection. It is a requirement that all personnel, regardless of normal duty assignments, be trained in manual toll collection.
- The Accounting Clerk is responsible for ensuring that all applicable CIP personnel have received the complete and proper training to prepare for cash toll revenue processing.
- The CIP Office Manager is responsible for ensuring that all Customer Service Representatives have received the complete and proper training to prepare for service center operations.
- The On-site Installation Manager and / or Lead Maintenance Technician is responsible for ensuring that all technicians and other applicable CIP personnel have received complete and proper training for lane equipment maintenance, particularly reactive maintenance.

4.25.2 New Employee Appraisals

Toll Collectors, Senior Toll Collectors, Plaza Shift Supervisors, Maintenance Technician, and Customer Service Representatives are hired on a probationary basis. The probationary period is 90 days. At the end of 90 days, the following appraisals will take place:

- The Plaza Shift Supervisors evaluate the Toll Collectors and Senior Toll Collectors.
- The Toll Superintendent evaluates the Plaza Shift Supervisors.
- The CIP Office Manager evaluates the Customer Service Representatives.
- The Toll Operations Manager evaluates the Maintenance Technicians with input from the Lead Technician and / or Installation Manager.

4.25.3 Annual Appraisals

Managers will follow the IMS guidelines for the timely appraisal of employees. Employees are evaluated annually.

4.26 Disciplinary Action

4.26.1 IMS Guidelines

Managers follow the IMS guidelines for appropriate disciplinary actions.

4.26.2 Documentation Requirements

Before any type of disciplinary action is taken against a CIP employee, a complete written report must be completed by the immediate supervisor and submitted to the Toll Operations Manager for review. Such a report should include written statements from witness, when applicable.

4.27 General Office Communications

4.27.1 The Toll Superintendent

The Toll Superintendent is the main channel of communication between the toll collection personnel and all other personnel. The Toll Superintendent meets with toll collection personnel as often as is necessary to ensure an open line of communication is maintained and that changes in policies and procedures are properly disseminated.

4.27.2 The CIP Office Manager

The CIP Office Manager is the main channel of communication for the Customer Service Center operation. The CIP Office Manager meets with CSC personnel as often as is necessary to ensure an open line of communication is maintained and that changes in policies and procedures are properly disseminated.

4.27.3 The Toll Operations Manager

The Toll Operations Manager ensures that all communications from IMS and / or SCDOT are properly disseminated to appropriate personnel. To ensure that an open line of communication between all CIP personnel is maintained, the Toll Operations Manager meets with the Toll Superintendent, CIP Office Manager, and Lead Maintenance Technician on a regular basis.

4.28 Safety, Security, and Maintenance

For safety and security reasons, the Cross Island Parkway Operations Building requires visitor registration, limited access by job function of CIP employees, and is not open to the general public.

Visitors are required to use the plaza (facing the lanes) entrance door, register with the on-duty Plaza Shift Supervisor, present photo identification, and may not enter secured areas or the tunnel without an authorized Parkway employee escort.

Movement within the Building by customers requiring emergency use of the restroom facilities will be closely monitored by the on-duty Plaza Shift Supervisor until the customer departs the building.

Tour groups sponsored by SCDOT or LMIMS require a minimum of 24-hours advance notice to the Toll Operations Manager or Toll Superintendent.

Employees may not bring visitors to the facility, including family members, without prior authorization from the Toll Operations Manager / designee.

4.28.1 Toll Collection Personnel

- Will report defective toll equipment to the Plaza Shift Supervisor
- Will not be permitted to leave their assigned tollbooth during their shift except when properly relieved or in the case of an emergency. When an emergency arises, use procedures outlined in sections 4.38 to 4.40.
- Will not allow anyone in the tollbooth while on duty, except at the direction of the Plaza Shift Supervisor for the purpose of relief, training, maintenance, or supervisory inspection
- Should never extend a hand to accept a toll with the arm and elbow in a stiff or rigid position while the customer's vehicle is moving. The instant the Toll Collector's hand comes in contact with the customer's hand, the Toll Collector should turn or swing to the left and allow the customer's hand to immediately follow along the line of travel of the vehicle.
- Should never attempt to reach inside of any vehicle, moving or otherwise, to collect a toll
- Should always be in a position of readiness at the toll window of the tollbooth as each vehicle enters the assigned lane. In the event that a customer loses control of the vehicle, the Toll Collector may then be in a better position to move out of the tollbooth for safety.

4.28.2 Toll Collection Personnel & Maintenance Technicians

- Should never attempt to conduct Parkway business while walking alongside a moving vehicle
- Should never open the door of a vehicle except in the case of an emergency
- Should never request the driver of a vehicle to push or tow another vehicle. Drivers should never back up in, or back out of a lane, unless in an extreme emergency.
- Should never request customers to get out of their vehicles to retrieve any object that may have fallen or been dropped in the lanes. CIP personnel provide a public service and should, therefore, offer to pick up the fallen object for the customer. However, objects should not be picked up until the vehicle is safely out of the way.

4.28.3 Plaza Shift Supervisor

- Ensures that Toll Collectors do not allow unauthorized personnel into the tollbooths
- Is responsible for ACM vault tracking. Specific vault tracking procedures have been established and approved by SCDOT. These procedures are identified in the Plaza Supervisor's User Manual.
- Regularly monitors all tunnels, doors, lanes, and buildings to ensure safety and security
- Periodically inspects the interior of tollbooths to ensure Toll Collector safety
- Verifies that all Toll Collectors perform all required inspections
- Immediately reports to the Lead Maintenance Technician any defective equipment or reported maintenance requirements. Immediately reports to the Toll Superintendent any damage to facilities.

4.28.4 All CIP Personnel

- Will cooperate in every way in the proper care and maintenance of all SCDOT buildings, grounds, furniture, fixtures, and equipment
- Will use facilities and equipment including heat, light, stationery, and similar commodities with due respect for economy, efficiency, and cleanliness
- Will not be permitted to use a personal television set on SCDOT property. If a radio is used, the volume is expected to be kept down to a level that provides no interference while working. No earphones are to be worn

when listening to the radio. No other personal electronic audio devices are permitted in the tollbooths or offices.

- Will cooperate to the fullest extent and comply with requests for assistance made by local police. The processing of traffic is of prime importance and any delays should be kept to a minimum.
- Will report each injury, no matter how slight, immediately, and secure medical treatment as directed by the Plaza Shift Supervisor. A complete report of the incident / accident is stated on the CIP Incident Report and is filed with the Plaza Shift Supervisor. All such incidents are handled in accordance with South Carolina State Law.
- Must always use the tunnel between the tollbooths and the Operations Building
- While in the lanes, should never step off the curb unless facing approaching traffic. Must always wear a safety vest while in the lanes.
- Should always be certain that no body parts project over the curb while standing in the lanes
- Should never offer any resistance in the event of a holdup
- Whenever handling currency and coins, should wash hands thoroughly before eating or drinking
- Should always use good judgment, follow established procedures, and conduct themselves in a businesslike manner

4.29 Supplies & Equipment

All requests for the purchase of supplies and equipment will be submitted to the CIP Office Manager utilizing a purchase requisition form. It is the responsibility of all personnel to ensure that requisitions are complete and accurate before submittal. The Toll Operations Manager and the CIP Office Manager must approve all requisitions.

The CIP Office Manager is responsible for maintaining an accurate inventory of all supplies and equipment utilizing a system that ensures accuracy and weekly tracking capability.

4.30 Robberies and Threats

4.30.1 Documentation

- CIP personnel experiencing robbery attempts or threats of any kind must document the incident(s) on the CIP Incident Report.
- If a description of the individual committing the robbery or robbery attempt is available, the CIP employee involved in the incident must complete the Suspect Description Form.

4.30.2 Procedures to follow

If the CIP employee is:

- Physically challenged for the amount of a toll (e.g., threatened with physical harm unless allowed to pass through the lane), is not drawn into a confrontation. Allows the customer to pass through the lane, and immediately notifies the Plaza Shift Supervisor. Although the VES will photograph the license plate of the vehicle, the employee should attempt to get the license plate number and state, as the vehicle exits the lane.
- Threatened by anyone wielding a weapon of any kind, does not resist, allows the person to pass through the lane, and immediately notifies the Plaza Shift Supervisor. Although the VES will photograph the license plate of the vehicle, the employee should attempt to get the license plate number and state, as the vehicle exits the lane.
- Held up by anyone demanding money, hands the entire cash drawer over immediately, and concentrates on the description of the robber. DOES NOT HESITATE OR RESIST IN ANY MANNER WHATSOEVER. If the robber hands the cash drawer back, takes it. The cash drawer may contain the robber's fingerprints. If possible, is careful not to smudge or add fingerprints. After the robbery:
 - ⇒ Calls 911
 - ⇒ Looks quickly for the vehicle license plate and state
 - ⇒ Notes the color and make of the vehicle and any distinctive markings or features
 - ⇒ Notifies the Plaza Shift Supervisor
 - ⇒ Completes the Suspect Description Form and Incident Report

4.31 Uniforms, Clothing and Equipment

4.31.1 Standard Uniform

The standard uniform for Toll Collection, Maintenance, and Service Center personnel shall include an IMS issued “golf” style shirt, light blue in color, with the name “Cross Island Parkway” embroidered across the left breast. Short-sleeved shirts will be worn during warm weather and long-sleeved shirts during cool weather.

- Each full-time employee will be issued 5 shirts.
- Each employee is responsible for the laundering and care of his/her shirts.
- Shirts must be turned into the CIP Office Manager upon termination of employment.
- Each part-time employee will be issued 2 shirts.
- Employees are required to provide their own trousers.
- Denim is not acceptable.
- Multi-colored pants are not acceptable.
- Workout or sweatpants are not acceptable.
- Shorts may be worn in the summer months.
 - ⇒ Athletic shorts or swimming gear are not acceptable.
 - ⇒ Multi-colored or denim shorts are not acceptable.
 - ⇒ A conservative length is required.

4.31.2 Other Clothing Requirements

All other personnel employed at the Cross Island Parkway are required to wear clothing that is considered “casual business attire.”

4.31.3 Equipment

Each employee will be issued a Key Identifier Card (swipe card) which is used to gain access to the toll facilities and to log-on to the computer system. A \$5.00 replacement charge will be levied for any loss or damage to an issued card.

A padlock and key will be issued for use with a personal locker, when available.

4.31.4 Equipment Issue Form

Uniforms and equipment will be issued via the Equipment Issue Form and signed for by each employee.

4.32 Scheduling

The Toll Superintendent and the CIP Office Manager are responsible for scheduling all personnel requirements to operate the Cross Island Parkway. The Toll Superintendent and the CIP Office Manager are also responsible for managing and maintaining records for attendance, punctuality, overtime, vacations, sick leave, and any other leave requests. The Plaza Shift Supervisor submits daily attendance records to the Toll Superintendent. Toll collection is a 24-hour, seven-day-a-week, 52-week-a-year operation. Therefore, it is essential that all shifts be properly staffed and supervised. IMS and SCDOT have policies in place that grant sufficient sick and vacation leave, and holiday privileges. The Plaza Shift Supervisor is responsible for setting a good example by not abusing these privileges.

- Plaza Shift Supervisor and Toll Collector schedules vary, providing for day, evening, and weekend shifts.
- Schedules are posted at least two weeks in advance.
- Any changes or substitutions must be requested in writing at least 72 hours in advance of the change to the immediate supervisor. The request is acknowledged in writing within 24 hours.
- Plaza Shift Supervisors and Toll Collectors are assigned to shifts for regular fixed hours. Generally, the policy is to honor the normally scheduled shift. However, assignments are governed by the need to ensure efficient Cross Island Parkway toll road operations. If necessary, normally scheduled shifts are changed.
- Plaza Shift Supervisors and Toll Collectors unable to report for work must notify their immediate supervisor or location of assignment two hours before the commencement of the shift. The Plaza Shift Supervisor or Toll Collector makes such reports via a personal telephone call. Telephone messages are not considered acceptable.

4.32.1 Holidays, Vacations, and Sick Leave

Holidays, vacations, and sick leave are as directed by IMS Human Resources Policies.

4.32.2 Tardiness/Absenteeism

- All personnel must be punctual at all times, are to be in uniform when appropriate, punched in, and ready to start their shift in accordance with their scheduled start time.



- Plaza Shift Supervisors are to be in uniform and ready for their assignment no later than five minutes prior to the scheduled time.
- Plaza Shift Supervisors and Toll Collectors must notify their immediate supervisor as soon as possible in the event of a delay in reporting to work.
- Plaza Shift Supervisors and Toll Collectors must not be tardy. Frequent tardiness may be subject to disciplinary action.

4.32.3 Overtime

Mandatory overtime may be required for Toll Collectors and Plaza Shift Supervisors to complete shift requirements during peak traffic or emergency situations. All full-time employees are salaried.

- Overtime compensation, when applicable, shall be straight time.
- Any period of time that is 2 hours or less, shall be considered hold-over time and not be payable as overtime.
- Plaza Shift Supervisors and Toll Collectors are offered overtime on a rotating schedule.
- The Plaza Shift Supervisors offer overtime to Toll Collectors on their shift on a rotating schedule. If no Toll Collector is available for work, Plaza Shift Supervisors can then refer to other shifts for available Toll Collectors.
- The Toll Superintendent offers overtime to Plaza Shift Supervisors on a rotating schedule.
- The schedule is kept in the Plaza Shift Supervisor's office.
- If a Toll Collector or Plaza Shift Supervisor is offered the opportunity to work overtime and refuses, the roster is marked as such, the Toll Collector or Plaza Shift Supervisor refusing overtime is moved to the bottom of the roster, and the next person on the list is contacted.
- The Plaza Shift Supervisor reviews Toll Collector overtime rosters periodically to ensure the rotation is being followed.
- The Toll Superintendent reviews Plaza Shift Supervisor overtime rosters weekly to ensure the rotation is being followed.

4.32.4 Holdover

In circumstances where it is necessary to hold over a Toll Collector or Plaza Shift Supervisor past their scheduled shift, a meal allowance is granted for periods of time in excess of four hours, providing a meal receipt is submitted.

4.33 Customer Relations

4.33.1 Purpose

This section helps the Toll Collectors, Customer Service Representatives and Plaza Shift Supervisors become professional and comfortable in dealing with the public. Most CIP personnel will come in contact with customers on a daily basis.

IMS provides Hilton Head and surrounding communities with a very special service, and IMS appreciates patron use of the toll roads. Both IMS and SCDOT want the public to feel good about using the Cross Island Parkway and the personnel that operate it.

At times, it may become necessary for Plaza Shift Supervisors and other CIP personnel to collect tolls. If this occurs, all CIP personnel, including the Plaza Shift Supervisors, should follow the same guidelines as the Toll Collector and Customer Service Representative.

The purpose of customer relations is to:


- Promote customer satisfaction
- Make everyone's job easier and more satisfying

By understanding customer relations, CIP personnel know:

- How to control each transaction smoothly and quickly
- Why customers act the way they do
- How to manage interpersonal conflict

CIP personnel responsibilities are:

- To present SCDOT with a professional, public image
- To process traffic through toll lanes quickly and efficiently
- To process customer service requests quickly and efficiently
- To know how to handle a variety of unexpected situations
- To provide information regarding travel routes in the general vicinity of the toll facility
- To handout business cards and materials on the Palmetto Pass and the Cross Island Parkway, when requested.
- To wear name badges, if available, and to post their nameplates, if available, on the tollbooth door or Service Center window while performing CIP duties
- To give their first name pleasantly and promptly to anyone, upon request



- To handle complaints and criticism from customers in a polite manner and immediately report them. Customer complaints must be documented on the Cross Island Parkway Patron Complaint Form.
- Not to resort to abusive language or violence of any kind. In the event of an argument, ask the customer to pull safely to the side of the road and call the Plaza Shift Supervisor immediately.

Patrons walking up to a tollbooth asking for assistance must be directed to remain on the road shoulder across from the tollbooth. The Toll Collector then notifies the Plaza Shift Supervisor.

Plaza Shift Supervisor responsibilities are:

- To understand customer service
- To wear proper uniform, dress, name badges, nameplates, etc.
- To communicate properly when dealing with the public
- To give instructions to patrons, i.e., filling out forms, giving road directions, or other procedures
- To deal effectively with patron complaints

4.33.2 Greeting / Appreciation

- The Toll Collector or Customer Service Representative must greet each customer.
- The Toll Collector or Customer Service Representative should thank each customer, every transaction, every day.
- If the Toll Collector or Customer Service Center Representative says only two words to a customer, it should simply be, "THANK YOU."

4.33.3 Knowledge

All CIP personnel should:

- Know what it takes to be a professional at all times
- Know how to direct customers to destinations
- Know how to handle emergency situations
- Follow carefully described procedures to ensure safety. The Plaza Shift Supervisor should be notified immediately of any problem threatening safety and security.

4.33.4 Appearance

All CIP personnel must look neat at all times. Appearance of CIP personnel includes dress, looks, and manners.

Always remember:

- CIP personnel represent SCDOT.
- Dress to convey nonverbal communication about job satisfaction.
- Neat and professional dress increases presence and authority when dealing with the public, and the public quickly feels good about Cross Island Parkway.
- A sloppy look, bad posture, or a scowling face can put the customer on the defensive, and the CIP employee's job becomes more difficult.
- Follow uniform guidelines at all times (as outlined in Section 3.9 of this SOP).
- With the daily pressures associated with serving hundreds of people face-to-face, it can be difficult maintaining a professional outlook. Being a professional means that when customers become annoyed with the toll road, for whatever reason, the CIP employee must maintain composure and continue to perform the job in a professional manner. The CIP employee must continue to:
 - ⇒ Work efficiently
 - ⇒ Think, and not feel
 - ⇒ Remain in complete control
- IMS wants the public to know professional treatment can be expected at all times.

4.33.5 Accuracy

Accuracy of a Toll Collector is important because it instills confidence in the customer and ensures that all transactions are appropriately handled and accounted for. Toll collector accuracy is dependent on the following:

- Correctly classifying vehicles
- Correctly counting the money the customer has given you
- Providing the customer with the correct change
- Correctly processing each transaction

4.34 Money Losses by CIP Personnel

In the event of a loss of money, other than errors in the normal collection and registration of tolls, an investigation is to be made. This investigation will determine the degree of carelessness, the work-related background of the Toll Collector, and all other extenuating factors that occurred during the shift.

Based on the results of the investigation, the Toll Operations Manager / designee makes a recommendation as to what disciplinary action is deemed appropriate. The following sections outline the possible outcomes of an investigation and those actions to be taken in each case.

4.34.1 Shortages and / or Overages

In the following types of losses, disciplinary action of the Toll Collector is mandatory, except in extraordinary cases:

- Records of Toll Collector collection activities of shortages or overages are tracked in increments of two weeks. If, at the end of the two-week period, the shortage is found to be excessive, the appropriate disciplinary action is taken (refer to Section 3.12.2).
- Shortages that are discovered or occur on the last day of a Toll Collector's employment

4.34.2 Disciplinary Action

In all cases of money loss due to carelessness, disciplinary action is considered. Such action consists of a letter of warning for a first offense and more severe action for any recurrence.

In keeping with this policy, it is incumbent upon the Toll Superintendent and Plaza Shift Supervisors to notice careless practices that could lead to losses and to take steps to stop them. This means that a letter of warning could be recommended for a Toll Collector, even though no money was lost.

All Toll Collectors must remain in good standing with IMS. IMS has developed a point system as an indicator for disciplinary actions that are required to be taken. The actions listed in Table 4-1 are guidelines. Each incident is reviewed on a case-by-case basis by the Toll Operations Manager / designee for determination of the final action.

STANDARD	POINTS ISSUED	ACTION
A single deposit with an error rate of less than \$5.00	None	This is the minimum standard which should be met by all personnel.
A single deposit with an error rate of \$5.00 or greater but less than \$10.00	One Point	Letter issued by Plaza Shift Supervisor notifying employee of discrepancy and point assigned. Retraining may be scheduled.
A single deposit with an error rate of \$10.00 or greater but less than \$25.00	Two Points	Letter issued by Plaza Shift Supervisor notifying employee of discrepancy and point assigned. Retraining may be scheduled.
A single deposit with an error rate of \$25.00 or greater but less than \$40.00	Three Points	Letter issued by Toll Superintendent notifying employee of discrepancy and point assignment. Employee is put on probationary status.
A single deposit with an error rate of greater than \$40.00	Four Points	Letter issued by Toll Operations Manager notifying employee of discrepancy, points assigned, and one-day suspension (unpaid).
	Accumulation of Six Points*	IMS terminates employee.

Table 4-1 Guidelines for Disciplinary Action Enforcement

*Points are cumulative. The following are examples of the possible point accumulation and the resulting disciplinary action.

- Two 1-point discrepancies result in a two-point disciplinary action.

Example: One point was issued on January 10, 1996 because of a \$5.50 discrepancy in the daily deposit. The Plaza Shift Supervisor issues a letter notifying the Toll Collector of the discrepancy and the point. On March 15, 1996, another point was issued because of a \$6.75 discrepancy in the daily deposit. The Plaza Shift Supervisor issues a letter notifying the Toll Collector of the discrepancy and the point issued.

- One 1-point discrepancy and one 2-point discrepancy result in a 3-point discrepancy.

Example: One point was issued on January 17, 1996 because of a \$5.50 discrepancy in the daily deposit. The Plaza Shift Supervisor issues a letter notifying the Toll Collector of the discrepancy and the point. Two points were issued on February 4, 1996 because of a \$11.50 discrepancy in the daily deposit. The Toll superintendent issues a letter notifying the Toll Collector of the discrepancy and the points issued. The Toll Collector is put on probation status.

- One 2-point discrepancy and one 4-point discrepancy would result in the 6-point disciplinary action.

Example: Two points were issued on June 10, 1996 because of a \$15.25 discrepancy in the daily deposit. The Plaza Shift Supervisor issues a letter notifying the Toll Collector of the discrepancy and the points. On August 4, 1996, four points were issued because of a \$45.00 discrepancy in the daily deposit. IMS terminates the Toll Collector for accumulated points.

Toll collector's revenue and deposits are reviewed on a daily basis. If any of the established performance standards are not met, the Toll Collector is subjected to the disciplinary action described in Table 4-1.

The total points are reviewed at the time of the two-month evaluation and appraisal for employees completing the introductory period. After this evaluation and the employee assumes permanent status, any points accumulated to date are erased and the process starts over. From this point on, points are reviewed every month on a rolling six-month basis by the Toll superintendent / designee.

4.35 Emergencies

In the event of an emergency, follow the procedures described in Sections 4.38 through 4.40.

4.36 Key Control

4.36.1 Key Control Responsibilities

It is the responsibility of the Toll Superintendent to maintain control of all keys at the CIP facility. This includes maintaining an accurate log of where every copy of every key is located and to whom each key is assigned.

4.36.2 Safe Keys

Holding Safe keys are extremely sensitive items. Every holding safe key must be accounted for at all times. Part of the shift changeover procedures for Plaza Shift Supervisors includes signature transfer of the holding safe key. All additional holding safe keys will be kept secure in a key control box located in the Toll Operations Manager's office.

4.36.3 Key Control Box

The Toll Superintendent, Office Manager, and Toll Operations Manager may only access the key control box, located in the Toll Operations Manager's office. An access log will be kept inside the box and must be completed whenever access to the box is necessary.

4.36.4 Key Inventory

An inventory of keys will be conducted on a monthly basis. The Toll Superintendent will accomplish this. A checklist will be used to verify all keys. Copies of sensitive keys will not be requisitioned or procured without the signed authorization of the Toll Operations Manager.

- The following keys are considered extremely sensitive:
 - ⇒ Vault Coin Boxes
 - ⇒ Cash Drawers

4.37 Telephone Use

It is expressly prohibited that CIP personnel use office or tollbooth telephones for making personal phone calls. Prior approval by the immediate supervisor is required for emergency personal phone calls to be made. The fax machine is not to be used for sending personal faxes.

All long distance phone calls or faxes must be logged on the CIP Telephone Log and submitted to the CIP Office Manager on a weekly basis.

4.38 Critical Lane Failures

4.38.1 Definition

A critical lane failure occurs when the following circumstances arise:

- An ACM in a ramp lane fails to accurately collect cash revenue
 - ⇒ Counts a coin multiple times
 - ⇒ Jams without self-recovering
 - ⇒ Miscounts coin denominations
- One or more plaza lanes fail during peak traffic hours causing a serious inconvenience to customers
- Power interruptions across all or the majority of plaza lanes at any time

4.38.2 Notifications

- If, during the course of a shift, a critical lane failure occurs, the following CIP personnel notifications must be made:
 - ⇒ On-duty or on-call Maintenance Technician
 - ⇒ Toll Superintendent
 - ⇒ Toll Operations Manager
- On a case-by-case basis, the Toll Superintendent or Toll Operations Manager will make a determination as to whether or not additional toll collection personnel must be called in to assist with ad hoc toll collection.
- If the critical lane failure is the result of a power failure and / or the failure of the UPS system, the following notifications will be made immediately:
 - ⇒ The local power company
 - ⇒ The Facility Maintenance Contractor
- If a power failure occurs during nighttime hours, the following additional notifications will be made:
 - ⇒ The police department
 - ⇒ SCDOT

4.38.3 Ramp Lanes

- Failure of the Automatic Coin Machines in either ramp lane is considered a critical lane failure and will require immediate action from on-duty CIP personnel.
- If there is no Maintenance Technician immediately available on-site and the failure occurs prior to the over-night shift change, the Plaza Shift Supervisor must drive to the ramp lane and attempt reactive repair of the ACM.
- If reactive repair attempts fail, the on-call Maintenance Technician must be contacted and notified of the lane failure.

- If traffic needs demand it, the Plaza Shift Supervisor must assign an available CIP employee to report to the ramp lane to conduct ad hoc toll collection procedures

4.38.4 Plaza Lanes

Correct operation of the canopy signal lights is a major factor in determining how critical failures at the Plaza lanes are. If the lights “freeze” in red (lane closed) mode and cannot be overridden, then it becomes necessary to have CIP personnel in the lanes directing traffic to enter the lanes that are available for toll collection. See manual traffic direction in section 4.40.2.

- Determination as to traffic flow impact must be made immediately by the on-duty Plaza Shift Supervisor.
- If there is no anticipated major inconvenience to customers as a result of lane failures, the on-duty Plaza Shift Supervisor need only notify the on-duty or on-call Maintenance Technician.

4.39 Emergency Evacuation Procedures

In the event that CIP staff are officially notified of an emergency evacuation of Hilton Head Island due to severe weather, the following notifications will be made:

- SCDOT
- Toll Superintendent
- Toll Operations Manager

4.39.1 Emergency Evacuation Assistance Plan

The Cross Island Parkway will be an integral component for the safe evacuation of residents and guests in the Hilton Head Island communities. As such, CIP personnel may be required to render assistance during the evacuation process. (No specific plan has been developed as of this submission.)

4.39.2 Immediate Evacuation

Under no circumstances will any CIP employee remain on-site if an official order for immediate evacuation is given. Toll Collectors, Customer Service Representatives, and any other personnel processing cash will immediately turn over all cash to the on-duty Plaza Shift Supervisor who will secure the cash in the on-site safe.

4.39.3 Timely Evacuation

In the event that official notification of an emergency evacuation allows time to disconnect and secure equipment and turn off power, the following steps should be taken:

- Disconnect MLT's and receipt printers in the booths and store them in the Maintenance Shop.
- Turn off and unplug all electrical equipment including computers, printers, copiers, etc.
- Secure all tollbooths
- Ensure that lane island traffic signals are securely mounted.
- Ensure that all cash is secured in the on-site safe.

4.40 Ad Hoc Toll Collection

Ad hoc toll collection is conducted only when one or more lanes are unable to properly process traffic. If traffic demands deem it appropriate, a problem lane should be closed until repair can be accomplished. If the demands of traffic require that all lanes be available for traffic processing, such as during rush hours, then the ad hoc toll collection procedures should be used.

4.40.1 Documentation

- Ad hoc toll collection is reported on the Ad Hoc Toll Collection Report.
- The CIP Shift Supervisor's Report must show, in detail, the reasons for using Ad Hoc toll collection - date, times, lanes, and Toll Collectors involved.
- The Accounting Clerk will use a Supplemental Revenue Deposit Report when preparing these funds for deposit.

4.40.2 Manual Traffic Direction

Manually directing traffic into toll lanes will only be attempted during critical lane failures where it is absolutely necessary to control traffic flow because of failed overhead canopy signal lights.

- CIP employees engaged in manual traffic directing must be wearing a safety vest. Additional reflective arm and leg bands must be worn during dark hours.
- Employees will be positioned out of the lanes of traffic but visible to approaching vehicles. Employees may stand between two lanes available for traffic processing and signal vehicles into both lanes using traffic batons.
- Employees will not attempt to direct traffic into lanes other than those lanes to the immediate right and left of where the employee is positioned.

4.40.3 Ad Hoc Toll Collection – Attended Lanes

Attended lanes are those lanes at the mainline barrier where either manual or AVI toll collection is possible. No ACM machines are available at this time. The Plaza Shift Supervisor or Toll Collector is required to collect and verify toll payments and record vehicle class information. Additionally, the Plaza Shift Supervisor may be required to conduct ad hoc toll collection at one of the ramp lanes should the equipment fail, but only until the ACM machine can be set up for ad hoc collection as per Section 4.40.4 below. Great care for personal safety should be observed while working in these lanes.

Plaza Shift Supervisors and Toll Collectors are provided with appropriate safety and operational equipment, listed below:

- Note: A change fund may not be necessary if ad hoc toll collection is being performed in a lane requiring patrons to have exact change.
- Standard uniforms for Toll Collectors and Plaza Shift Supervisors, as described in Section 4.3
- Toll collectors' change funds, as described in Section 4.8.1 (as required)
- Coin dispensers or change aprons
- Small calculator (optional)
- Ad Hoc Toll Collection Report and a supply of appropriate forms such as preprinted receipt forms, Cross Island Parkway Patron Complaint Forms, and Cross Island Parkway Unusual Occurrence & Exception Report Forms
- Clipboards and pens / pencils
- Chairs (optional)
- Water
- Walkie-talkies or portable phones for communications with toll booths (for emergency use or to request a brief break)

Some of the above items are mandatory and others are issued based on current need. Additional pieces of equipment may be supplied at the discretion of the IMS Toll Operations Manager/designee.

- The number and class of vehicles being processed should be recorded on the Ad Hoc Toll Collection Report. This information is forwarded to the Toll Superintendent to aid in reconciliation.
- Ad hoc toll collection funds and the Ad Hoc Toll Collection Report are kept separate from all other funds and are placed in a separate Revenue bag provided by the Plaza Shift Supervisor.
- After the funds and the Ad Hoc Toll Collection Report are placed in the Revenue bag, the Revenue bag is sealed.
- The Revenue bag is kept in the tollbooth until the end of the shift.
- At the end of the shift, the Plaza Shift Supervisor deposits the Revenue bag(s) into the on-site safe. The Plaza Shift Supervisor signs the Deposit Transfer Log.
- Resumes normal toll collection when the malfunction has been corrected.

4.40.4 Ad Hoc Toll Collection – Unattended Lanes

Unmanned ad hoc toll collection is performed under the following conditions:

- Scheduled PM
- ACM malfunction
- Emergency lane closure, i.e., accidents, chemical spills on the toll road, etc.

If the lane closure is due to an ACM failure, the system operator notifies the Plaza Shift Supervisor, and the Plaza Shift Supervisor goes to the location and attempts to correct the malfunction.

If the Plaza Shift Supervisor cannot correct the ACM malfunction, he notifies the on-duty or on-call Maintenance Technician to repair the ACM.

The Plaza Shift Supervisor documents the malfunction on the Cross Island Parkway Shift Incident Report.

If required, the Plaza Shift Supervisor performs ad hoc toll collection, as described in Section 4.40.3, until the Maintenance Technician arrives.

After the Maintenance Technician arrives and it is determined that the lane can safely remain open, the Plaza Shift Supervisor and the Maintenance Technician initiate ad hoc toll collections as follows:

- Even though the ACM is malfunctioning, traffic is still being monitored and recorded. The Toll Superintendent reconciles the supplemental deposit of unmanned ad hoc toll collections based on the actual traffic count, not the funds collected.
- A sign is placed above the ACM basket indicating the amount of the toll to be paid based on vehicle axle count.
- The Maintenance Technician places a container underneath the ACM basket.
- Patrons deposit the correct toll in the container and proceed through the red light.
- After the ACM malfunction has been corrected, the Maintenance Technician notifies the Plaza Shift Supervisor who reports to the location.
- The Maintenance Technician removes the sign that was placed above the ACM basket and removes the container containing the collected tolls from the ACM.
- It may be necessary to pick up any coins that may have been dropped.
- The Maintenance Technician empties the collected tolls from the container into a Revenue bag provided by the Plaza Shift Supervisor.

- The Plaza Shift Supervisor documents the time the malfunction was corrected on the Cross Island Parkway Shift Incident Report.
- The Plaza Shift Supervisor takes possession of the Revenue bag from the Maintenance Technician and records the collected tolls using the Supplemental Revenue Sheet.
- The Plaza Shift Supervisor places the original Supplemental Revenue Sheet and the funds in a Revenue bag and seals the Revenue bag.
- The Plaza Shift Supervisor locks the Revenue bag in the ACM for pick-up by the armored car carrier.

5. Login / Application Access / Exit Session

5.1 Login

5.1.1 Purpose


The login process provides security and access only to the users that are authorized to use the system.

5.1.2 Process


1. Double-click on the **Login** icon that is available on the **Program Manager** window.
2. The **Login** window is displayed:

3. Enter **User ID** . Press  .

4. Enter the **Password** .

5. Click on  .

Or

6. Press  . The **Cross Island Parkway Toll Collection System** screen is displayed with various options.

5.2




Application Access

5.2.1 Purpose

On the lower right-hand corner of the Main Screen are various buttons. They allow the user to access different applications after successfully logging into the system:

5.2.2 To Access the ETC Applications

1. Click on the icon to access the **Maintenance On-Line Management System - MOMS** application.
 - Maintenance Personnel (Total Access)
 - Toll Superintendent (Total Access)
 - Toll Operations Manager (Total Access)
 - Plaza Shift Supervisors (Total Access)
 - Account Clerks (View Only)
2. Click on the icon to access the **Service Center ETC Account Management System** application.
 - Customer Service Representatives (Total Access)
 - Office Manager (Total Access)
 - Toll Operations Manager (Total Access)
 - Toll Superintendent (View Access)
 - Account Clerks (Total Access)
3. Click on the icon to access the **Host / Revenue & Reconciliation** application.
 - Customer Service Representatives (Limited Access)
 - Toll Collectors (Limited Access)
 - Toll Superintendent / Plaza Shift Supervisors (Total Access)
 - Account Clerks (Total Access)
 - Toll Operations Manager (Total Access)
 - Office Manager (Total Access)



4. Click on the icon to access the **Schedule** application.
 - Toll Superintendent (Total Access)
 - Account Clerks (Limited Access)
 - Toll Operations Manager (Total Access)
 - Plaza Shift Supervisors (Limited Access)
5. Click on the icon to access the application **System Administration** application.
 - Toll Operations Manager (Total Access)
 - Office Manager / Toll Superintendent (Limited Access)
6. Click on the icon to access the **Supervisor Lane Monitor** application.
 - Toll Superintendent / Plaza Shift Supervisors (Total Access)
 - Account Clerks / Maintenance personnel (Total Access)
 - Toll Operations Manager (Total Access)
 - Office Manager (Total Access)
7. Click on the icon to access the **Supervisor Lane Monitor On-Line Help**.
 - Toll Superintendent / Plaza Shift Supervisors (Total Access)
 - Account Clerks / Maintenance personnel (Total Access)
 - Toll Operations Manager (Total Access)
 - Office Manager (Total Access)
8. Click on the icon to access **General Help**. This provides initial help on the logging in process and brief information on all of the applications.

5.2.3 Access Host / Revenue Reconciliation Application


5.2.3.1 Purpose

The Host / Revenue Reconciliation application is accessed to carry out the following functions:

- Assign Seed / Revenue Bags
- Make Vault and Bank Deposits
- Reports

5.2.3.2 Access

1. Click on the icon to access the **Host / Revenue Reconciliation** application.
2. The following screen is displayed:



5.3




Exit Session

5.3.1 Purpose

Each application must be closed separately. This will return the user to the Main Screen. From this screen, the “Exit Session” button is pressed. This will close the application altogether. In order to re-enter, the user must login to the application.


5.3.2 Process





1. Click on .
2. The application closes.


6. Using Windows Applications

6.1 Using a Mouse


A  is used to 'Point and Click' at objects on the computer screen or windows within the screen.



1. Place your hand over it so that your index finger rests on the left button.
2. Move the  over the mouse pad to move the cursor across the screen.
3. Place the cursor over the buttons on the screen, for example:



Or

 radio button

Or


the  on List Drop Box 

4. Press the left button down. This is called a "Click".
5. When instructed to "Double-click", quickly press the left button twice in succession.



6.2 Menus & Toolbars

The menus and toolbars are displayed on the screen. Click on any one of the buttons or main menu names to access help directly from this screen.

6.2.1 To Use the Main Menu Bar

1. Use the  and click on the main topic that is to be accessed. A drop-down menu is displayed.
2. Click on the process that is to be carried out to access the correct window.

6.2.2 To Use the Main Toolbar

1. Use the  and allow the pointer to rest on any of the buttons such as .
2. Click on the left mouse button to open the window that corresponds to the function that is to be used.

6.3 Tab Folders

When each process is opened, a set of tab folders is displayed. This allows the user to view all of the sub-processes that can be carried out and allows simple access to each.


6.3.1 Process

A series of **tab folders** is displayed when any of the processes are opened. The **Open Account** tab folders are displayed as an example:

Demographics	SubAccounts	Replenishments	Vehicles	Device Request	Plan
Account Type	Agency	Account No.	Social Sec. No.		
PRIVATE					

When the system opens a subsystem, it will default to the first tab folder, displaying the folder information.



6.3.1.1 To Change to a New Folder within the Subsystem

1. Using the , click on the new tab folder title located at the top of the folder.
2. The open folder will close and the new folder will open.

6.4 List Drop Box Selections

List Drop Boxes are white fields characterized by an arrow button to the right. The List Drop Boxes are designed to allow the user to view authorized values and select the one that best applies.

6.4.1 To Use a List Drop Box



1. Click on the  on the right of the List Drop Box. A list of authorized entries will drop-down from the field.
2. With the  , click on the desired selection to highlight. The List Drop Box closes, displaying the selection in the field.

6.5 Data Windows

In many of the Tab Folders there is a data window. This area displays data that is entered into the system.

6.5.1 To View All Selections in a Data Window

If there are more selections than those displayed in the data window, there are scroll bars on the right side and at the bottom of the window.

1. Click on the , holding down the left mouse button. This causes the data window to scroll, displaying all authorized entries.
2. To scroll up, click on the  of the scroll bar.

6.6





Scroll bars



Scrollbars are used in several distinct places:

- List Drop Boxes
- On-Line Training
- On-Line Help



6.6.1 To Use a Scroll bar in a List Drop Box

1. Click on the  on the right of the List Drop Box. A list of authorized entries drops down from the field.



2. When there are more selections than those visible in the data window, a scroll bar on the right side of the List Drop Box is displayed (as shown).
3. Click on the , holding down the left button of the mouse. This causes the List Drop Box to scroll, displaying all authorized entries.
4. To scroll up, click on the .
5. Highlight desired selection.
6. The List Drop Box closes, displaying the selection in the field.

6.6.1.1 To Use a Scroll bar in On-Line Training, On-Line Help or the Application

1. When there is more text than is visible in the data window, a scrollbar on the right-hand side of the help screen is displayed.
2. Click on the  , holding down the left mouse button. This causes the text to scroll, displaying additional information.
3. To scroll up, click on the  .

6.7 Buttons & Hotkeys

There are three button types:

- Toolbar Buttons
- Command Buttons
- Radio Buttons






6.7.1 How to Use Toolbar Buttons

Toolbar buttons bring up an application window.

1. Place cursor on toolbar button. A small balloon pop-up is displayed describing the function of the button.
2. Click on the button to open corresponding window.


6.7.2 How to Use Command Buttons



Command buttons are usually displayed at the bottom of a window. They are used to save, cancel or delete information entered in that window.

1. Click on the command button to carry out a save, cancel or delete function in a window.
2. Normally a ,  or  pop-up displays, requiring the user to click on  or .



6.7.3 How to Use Radio Buttons

Radio buttons allow a selection within the application.





1. A radio button is displayed as .
2. Click on the radio button . A black dot is displayed in the center of the button and the function is triggered.

6.7.4 How to Use Hotkeys


Hotkeys are made available to the user that prefers using a  to a . The hotkeys can be used instead of buttons or drop-down menus.

1. On the Main Toolbar, each Main Menu title has a letter underlined, for example File.
2. Press <Alt> **F**. The **F**ile menu drops down.

Use the arrow   to move up and down the menu until the desired selection is highlighted.

Or

Press <Alt> * (* represents the hotkey letter of the menu item selection).

3. Press . The selected window is displayed.


7. Using On-Line Help


7.1 Toolbar Buttons

<u>F</u> ile <u>E</u> dit <u>B</u> ookmark <u>O</u> ptions <u>H</u> elp							
C <u>o</u> ntents	S <u>e</u> arch	B <u>a</u> ck	P <u>r</u> int	<<	>>	G <u>l</u> ossary	C <u>l</u> ose

The toolbar shown above can be used to get detailed information on each function. Each button is described in the following section.


7.1.1 Contents

The  provides the top level topic of all functions in the On-Line Help application.


1. Click  on the top help toolbar to return to the contents at any time.








2. Use the  to view a complete listing.

3. Click  at the top toolbar to return to the main **Help Basics** window.



7.1.2 Print

1. Click  to print the topic that is active.
2. The following Print window is displayed:





3. If  is pressed in error or a decision was made NOT to print the topic, click .
4. Click on  to print the topic.
5. Click  at the top toolbar to return to the main window.



7.1.3 Back

1. Click  to return to a previously viewed topic.
2. Click  at the top toolbar to return to the main window.

7.1.4 Back Browse Button <<


1. Click  to go back one screen at a time in topic sequence.
2. Click  at the top toolbar to return to the main window.

7.1.5 Forward Browse Button >>


1. Click  to go forward in topic sequence.
2. Click  at the top toolbar to return to the main window.




7.1.6 Search

1. Click  to display the following window:



7.1.6.1 Index





1. Type in a word or phrase or use the  to locate the desired subject.
2. Click . The On-Line Help jumps directly to the subject.
3. Click  at the top toolbar to return to the main window.

7.1.6.2 Find


1. For a more narrow search, click on the **Find** tab folder.
2. Type in a word or phrase in the **first** data window.


Either





use the  to locate a word in the **second** data window

Or




use the  to locate a topic in the **third** data window.

3. Click . The On-Line Help jumps directly to the subject.
4. Click  at the top toolbar to return to the main window.



7.1.7

Glossary

Glossary

1. Click **Glossary** to view the alphabetically listed terms that are defined within the system.
2. The terms are underlined with a broken dotted line and have a definition  that will pop-up.



3. Use the  to find the term. The terms are in alphabetical order.
4. Place the cursor on the term. The cursor now displays as a . Click on the term to jump to the system function dealing with the term.
5. Click **Back** at the top toolbar to return to the main **On-Line Help Course** window.

7.1.8

Exit

Exit

1. Click **Exit** to close On-Line Help.
2. The file closes.
3. Click **Back** at the top toolbar to return to the main **On-Line Help Course** window.


7.2 Special Features

7.2.1 If Statements

All contingencies, or **If statements** are printed in red. The purpose is to alert the user that within the steps of the procedure, the contingencies are to be followed only if applicable.

7.2.2 Jumps or Hotspots

1. All Jumps / Hotspots are green and underlined with a broken line.
2. Graphics can function as **Jumps** or **Hotspots**, see Section 7.3.


3. To display all jumps in a topic, press CTRL + 

7.2.3 Secondary Windows


1. Under each **How to Access** is a window name that is Green. Double-click on the word and the Secondary Window will be displayed on the right hand side of the screen.
2. Click on the button to open the secondary window and more detailed information will pop-up over the main window.
3. For more information, see **Secondary Windows**, section 7.4.

7.3 Jumps or Hotspots



Help topics can include graphics and text that link to other Help topics or to more information about the current topic. These are called jumps.


1. Jumps are identified by bold colored text and solid underline.
2. When pointing to a jump, the pointer changes to a hand shape .

7.3.1 To Choose A Jump


1. Point to the text or graphic, and click with the left  button.

Or

press  to select the jump, and then press .

2. Press **SHIFT**+ to move backward and select a jump.
3. If the jump chosen is linked to another topic, that topic appears in the Help window.
4. Sometimes a jump is linked to information that appears in a pop-up window or a secondary window. See section 7.4 for **Secondary Window**.
5. When information is displayed in a pop-up window, the size of the pop-up window is proportional to the size of the main Help window.

Note: To enlarge the pop-up window, change the size of the main Help window.

6. To display all jumps in a topic, press **CTRL**+.








7.3.2 To Close A Pop-Up Window

Click anywhere on the screen, or press any key.



7.4 Secondary Windows

Another type of link that is used in the On-Line Help is 'Secondary Windows'. The following links are used to create Secondary Windows:

1. Under each Process are buttons stating, "To change plaza, use the  to click on Trends." Click on the button to open the secondary window.
2. Click on the secondary window link and a secondary window will pop-up over the main window giving the specified procedure. Two buttons linked specifically to the secondary window are displayed at the top,  and .
3. To close, click .
4. To print the 'secondary window', click .
5. In order to enlarge the window, click  in the top right-hand corner of the screen. The window will fill the screen and permit full view of the windows.
6. To return to original size, click  in the top right-hand corner of the screen. This will return the window to its original size.

7.5 Defining and Using Bookmarks

Just as bookmarks can be placed in a book to mark specific references, bookmarks can be placed in Help topics that are used frequently. After placing a bookmark in a topic, the topic can be accessed quickly from the Bookmark menu.

7.5.1 Placing a Bookmark in a Topic

1. From the Bookmark menu in Help, choose Define.
2. In the Bookmark Name box, the topic title appears. If you want to use a different name to identify the bookmark, type a name in this box. Otherwise, the topic title that appears will be the name it is identified as the bookmark.
3. Click on the **OK** button.
4. The bookmark name now appears on the Bookmark menu in Help.

7.5.2 Viewing a Bookmark in a Topic

1. From the Bookmark menu in Help, choose the bookmark name for the topic to be viewed.
2. Underlined numbers precede the first nine bookmark titles.
3. Type the corresponding number to go quickly to a marked topic.
4. If more than nine bookmarks have been defined, choose **More** from the Bookmark menu in Help.
5. Select a bookmark in the **Go To Bookmark** box, and then choose the **OK** button.

7.5.3 Removing a Bookmark

1. From the Bookmark menu in Help, choose **Define**.
2. Select the bookmark to be removed.
3. Choose the **Delete** button.
4. The bookmark name is removed from the Bookmark menu in Help.

Glossary of Terms

ACM

Automatic Coin Machine

AVI

Automatic Vehicle Classification

CCTV

Closed Circuit Television

CIP

Cross Island Parkway

CSR

Customer Service Representative

ETC

Electronic Toll Collection

LMIMS

Lockheed Martin IMS

MLT

Manual Lane Terminal

MOMS

Maintenance On-Line Management System

PC

Personal Computer

LOCKHEED MARTIN



SCDOT Toll Collector User Manual Rev. 0.0

SC_DOT\Toll_Coll\Rev_0.0\TollColl.doc

Proprietary Data

PIN

Personal Identification Number

RF

Radio Frequency


SCDOT

South Carolina Department of Transportation

VES

Violations Enforcement System

LOCKHEED MARTIN



SCDOT Toll Collector User Manual Rev. 0.0

SC_DOT\Toll_Coll\Rev_0.0\TollColl.doc

Proprietary Data